

SX-695



End User Guide

Hospitality

INDEX

Power Switch	5
Rear Display	6
Cash Drawer	7
Key Lock	8
Paper Rolls	9 – 10
Programming Layout	11
Date & Time	12
Basic Sale /Split Payment	13
Multiple Sale/Quick Tender Keys/Receipt On/Off	14
Cancel/Return	15
Void/Last Item Void	16
No Sale/Discount	17 – 19
Easy Price & Name Change	20 – 24
Clerk Interrupt	25 – 26
Table	27 – 28
Deposit	29
Modifiers	30
Major Levels	31
Menu Windows	32 – 34
X/Z Report	35 – 36
Error Messages	37 – 38
F.A.Q	39
Glossary	40 – 43

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/towa/SX-695> and Geller SX-695 user guide Hosp

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)