

SX-695



End User Guide

Retail

INDEX

Power Switch	5
Rear Display	6
Cash Drawer	7
Control Lock	8
Paper Rolls	9 – 10
Scanner	11
Programming Layout	12
Date & Time	13
Retail Preloaded/Newspapers	14 - 15
Basic Sale/Split Payment	16 – 17
Multiple Sale/Quick Tender Keys/Price Check	18
Receipt On-Off/Cancel	19
Return/Void	20
Last Item Void/No Sale	21
Discount	22 – 24
Clerk Hold	25
Easy Price & Name Change	26 – 27
PLU Delete	28
Stock	29 – 30
Re-Ordering	31
Age Verification	32 – 33
Shelf Edge Labels	34
Mix & Match/Cashback	35
X/Z Report/Housekeeping	36 - 38
Error Messages	39 – 40
F.A.Q	41
Glossary	42 – 45

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/towa/SX-695> and Geller SX-695 user guide Retail

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)