

REPAIR MANUAL

LX-5600

[LX5600]DRE-002



TABLE OF CONTENTS

I. GENERAL EXPLANATION

1. CONNECTION DIAGRAM.....1

II. TERMINAL LIST OF PRINTER

1. M-U420.....1
 1-1. Connector Pin Arrangement1
 1-2. Connector Pin Assignments1

III. ILLUSTRATION OF ECR ASSEMBLY & MACHINE PARTS LIST

ILLUSTRATION OF ECR ASSEMBLY1
 MACHINE PARTS LIST.....13

IV. UNIT PARTS LIST

1. MPU UNIT UE2 (141).....1

V. RECOMMENDED PARTS LIST

1. MACHINE.....1

VI. DRAWING LIST

Unit name	Circuit name	Revision	Page
MPU UNIT UE2 (141)	ASSEMBLY CIRCUIT	1.31	1/9
	POWER SUPPLY CIRCUIT	1.31	2/9
	CPU CIRCUIT	1.31	3/9
	MEMORY CIRCUIT	1.31	4/9
	LCD CONTROL CIRCUIT	1.31	5/9
	IO CIRCUIT	1.31	6/9
RT UNIT 311	SERAIT CIRCUIT	1.31	7/9
	KEYBOARD CIRCUIT	1.31	8/9
	PRINTER CIRCUIT	1.31	9/9
KEYBOARD	STROKE KEYBOARD	020401	1/1
	FLAT KEYBOARD	020401	1/1

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/uniwell/LX-5600 service manual.html](https://the-checkout-tech.com/manuals/uniwell/LX-5600%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)