

# ***REPAIR MANUAL***

***LX-5600***

[LX5600]DRE-002



# TABLE OF CONTENTS

## I. GENERAL EXPLANATION

1. CONNECTION DIAGRAM.....1

## II. TERMINAL LIST OF PRINTER

1. M-U420.....1  
     1-1. Connector Pin Arrangement .....1  
     1-2. Connector Pin Assignments .....1

## III. ILLUSTRATION OF ECR ASSEMBLY & MACHINE PARTS LIST

ILLUSTRATION OF ECR ASSEMBLY .....1  
 MACHINE PARTS LIST.....13

## IV. UNIT PARTS LIST

1. MPU UNIT UE2 (141).....1

## V. RECOMMENDED PARTS LIST

1. MACHINE.....1

## VI. DRAWING LIST

Unit name	Circuit name	Revision	Page
MPU UNIT UE2 (141)	ASSEMBLY CIRCUIT	1.31	1/9
	POWER SUPPLY CIRCUIT	1.31	2/9
	CPU CIRCUIT	1.31	3/9
	MEMORY CIRCUIT	1.31	4/9
	LCD CONTROL CIRCUIT	1.31	5/9
	IO CIRCUIT	1.31	6/9
RT UNIT 311	SERAIT CIRCUIT	1.31	7/9
	KEYBOARD CIRCUIT	1.31	8/9
	PRINTER CIRCUIT	1.31	9/9
KEYBOARD	STROKE KEYBOARD	020401	1/1
	FLAT KEYBOARD	020401	1/1

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*