

# ***REPAIR MANUAL***

***NX-5400***

[NX5400]DRE-002

 **Uniwell**

# TABLE OF CONTENTS

## I. GENERAL EXPLANATION

1. CONNECTION DIAGRAM .....1

## II. TERMINAL LIST OF PRINTER

1. M-U420 .....1  
 1-1. Connector Pin Arrangement .....1  
 1-2. Connector Pin Assignments .....1

## III. ILLUSTRATION OF ECR ASSEMBLY & MACHINE PARTS LIST

ILLUSTRATION OF ECR ASSEMBLY.....1  
 MACHINE PARTS LIST .....13

## IV. UNIT PARTS LIST

1. MPU UNIT UE1 .....1  
 2. INTERFACE UNIT UE1 .....4

## V. RECOMMENDED PARTS LIST

1. MACHINE .....1  
 2. UNIT .....1

## VI. DRAWING LIST

Unit name	Circuit name	Revision	Page
MPU UNIT / INTERFACE UNIT / DISPLAY UNIT	ASSEMBLY CIRCUIT	1.68	1/8
	POWER SUPPLY CIRCUIT	1.68	2/8
	CPU ROM/ RAM CIRCUIT	1.68	3/8
	KEY/DISPLAY CTL CIRCUIT	1.68	4/8
	INTERFACE CIRCUIT	1.68	5/8
	DISPLAY CIRCUIT	1.68	6/8
	PRINTER CIRCUIT	1.68	7/8
	MEMORY CIRCUIT	1.68	8/8
KEYBOARD	STROKE KEYBOARD	020401	1/1
	FLAT KEYBOARD	020401	1/1

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*