

REPAIR MANUAL

UX-40/40F

[UX40]DRE-01-005

 **Uniwell**

TABLE OF CONTENTS

I. GENERAL EXPLANATION

1. Connection Diagram.....	1
----------------------------	---

II. EXPLANATION OF BLOCKS

1. Primary Power Block Circuit	1
1-1. Fuse.....	1
1-2. Transformer.....	1
2. Secondary Power Block Circuit	2
2-1. Block Diagram of Power Block Circuit.....	2
3. Logic Block Circuit	2
3-1. Block Diagram of Logic Block Circuit.....	2

III. SERVICE PROGRAMMING

1. Initial Reset.....	1
2. Test Program.....	1
2-1. RAM Test	1
2-1-1. Display Messages.....	1
2-2. ROM Test.....	1
2-3. Hardware Test	2

IV. ILLUSTRATION OF ASSEMBLY & MACHINE PARTS LIST

UX-40/40F Illustration of ECR assembly	1
UX-40/40F Parts List	2
Keyboard (Stroke key)	3

V. UNIT PARTS LIST

1. M1 MAIN UNIT UX-40 (PWB NAME:3REEB13006701C).....	1
2. PW BOARD ASS'Y M2 FRONT	3
3. PW BOARD ASS'Y M3 REAR.....	3

VI. RECOMMENDED PARTS LIST

1. Machine	1
2. Unit.....	1

VII. DRAWING LIST

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/uniwell/UX-40 UX-40F service manual.html>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)