

# REPAIR MANUAL

*UX-43/43F*

[UX43]DRE-01-005

 **Uniwell**

# **TABLE OF CONTENTS**

## **I. GENERAL EXPLANATION**

1. Connection Diagram.....	1
----------------------------	---

## **II. EXPLANATION OF BLOCKS**

1. Primary Power Block Circuit .....	1
1-1. Fuse.....	1
1-2. Transformer .....	1
2. Secondary Power Block Circuit .....	2
2-1. Block Diagram of Power Block Circuit .....	2
3. Logic Block Circuit .....	2
3-1. Block Diagram of Logic Block Circuit.....	2

## **III. SERVICE PROGRAMMING**

1. Initial Reset.....	1
2. Test Program.....	1
2-1. RAM Test.....	1
2-1-1. Display Messages.....	1
2-2. ROM Test .....	1
2-3. Hardware Test.....	2

## **IV. ILLUSTRATION OF ASSEMBLY & MACHINE PARTS LIST**

UX-43/43F Illustration of ECR assembly .....	1
UX-43/43F Parts List .....	2
Keyboard (Stroke key) .....	3

## **V. UNIT PARTS LIST**

1. M1 MAIN UNIT UX-43 (PWB NAME:3RN4B13000041B).....	1
2. PW BOARD ASS'Y M2 FRONT .....	3
3. PW BOARD ASS'Y M3 REAR.....	3

## **VI. RECOMMENDED PARTS LIST**

1. Machine .....	1
2. Unit.....	1

## **VII. DRAWING LIST**

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/uniwell/UX-43 UX-43F service manual.html>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)