

CITIZEN

Service Manual

Model : CBM-230/231

Japan CBM Corporation  
Information Systems Div.

Contents

1. ASSEMBLING / DISASSEMBLING PROCEDURE.....3

    1. HOW TO REMOVE PRINER COVER.....3

    2. HOW TO REMOVE TOP COVER.....4

        2.1 REMOVE PAPER END HOLDER FROM TOPCOVER.....4

        2.2 REMOVE SWITCH COVER FROM TOP COVER .....4

        2.3 REMOVE OPERATION PANEL BOARD FROM TOP COVER.....4

    3.REMOVE MECH.BRACKET UNIT.....5

        3.1 REMOVE AUTO CUTTER FROM MECHA.BRACKET (CBM231).....5

        3.2 REMOVE PRINTER MECHANISM FROM MECHA. BRACKET .....5

        3.3 REMOVE HEAD UP LEVER FROM MECHA. BRACKET (CBM-231) .....5

        3.4 REMOVE CUTTER LOCK LEVER FROM MECHA. BRACKET .....5

        3.5 REMOVE PAPER CUTTER FROM PRINTER MECHANISM.....5

        3.6 REMOVE FG PLATE FROM PRINTER MECHANISM .....5

    4. REMOVE CONTROL BOARD .....6

    5. REMOVE POWER BOX.....6

    6. REMOVE SWITCHING POWER SUPPLY.....7

2. CIRCUIT DIAGRAM .....8

    BLOCK DIAGRAM.....9

    CIRCUIT BIAGRAM : SERIAL INTERFACE.....10

    CIRCUIT DIAGRAM : PARALLEL INTERFACE ..... 11

    CIRCUIT DIAGRAM : OP PCB ASSY ..... 12

    CIRCUIT DIAGRAM : PE PCB ASSY.....13

3. SERVICE PARTS LIST.....14

\*For detailed information of LT-380 printer mechanism and AC-130 Auto Paper Cutter unit, please refer to the separate service manual

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/Citizen/CBM-230> and [CBM-231](https://the-checkout-tech.com/manuals/Citizen/CBM-231) service manual.

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)