

CITIZEN

Service Manual

DOT MATRIX PRINTER
MODEL CBM-710/720

Rev.1.00 Newly issued on Mar, 1989

Japan CBM Corporation

CONTENTS

Chapter 1. Printer Disassembly and Assembly	1
1 How to Remove Upper Cover and Rear Cover	2
2 How to Remove The Printer Mechanism	3
3 How to Remove the Control Board	3
4 How to Remove the Power Board and AC power Unit	4
5 How to Remove the Auto Cutter (CBM-720 only)	5
6 How to Remove the Operation Panel and PE Sensor	5
Chapter 2. Circuit Description	6
1 Outline	7
2 CPU Peripheral Circuit	8
3 Printer Control Circuit	10
4 Cutter Control Circuit	11
5 Interface and Operation Panel	12
6 Paper End Sensor Circuit	13
7 Parallel Interface Circuit	14
8 Serial Interface Circuit	16
9 RS422A interface Circuit	18
10 Power Supply Circuit	19
Chapter 3. Auto Cutter	20
1 Maintenance and Handling	21
2 Mechanism and Principle of Operation	22
3 Repairing and Troubleshooting	24
4 Disassembly and Assembly	26
Chapter 4. Circuit Diagram	28
1 Power Supply Circuit	29
2 Noise Filter Circuit	30
3 Operation Panel Circuit	30
4 Paper End Sensor Circuit	30
5 OP Junction Circuit	31
6 Parallel	32
7 RS232C	33
8 PS422A	34
Chapter 5. Parts List	35
1 Exploded View	36
2 Block Diagram	41
3 Power Supply Unit	43
4 Noise Filter Unit	45
5 Control Board Unit: RS232C	47
6 Control Board Unit: Parallel	51
7 Control Board Unit: RS422A	55
8 OP Panel/PE Detector/OP Junction Unit	59
9 Auto Cutter	63
10 Winder	67

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Citizen/CBM-710 and CBM-720 service manual.h](https://the-checkout-tech.com/manuals/Citizen/CBM-710%20and%20CBM-720%20service%20manual.h)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)