

CITIZEN

Service Manual

TERMINAL SLIP PRINTER

MODEL CBM-820

Rev.1.00 First created July.21st, 2000

Japan CBM Corporation

CHAPTER 1 ADJUSTMENTS

1

Some of the features of this printer require minor adjustments in order to ensure optimal performance. This chapter explains how to make these adjustments. Please make sure to check that all of these adjustments are maintained whenever the printer is serviced or parts are changed.

1. Tools and measures	3
2. Adjusting the gap between the print head and platen	4
2-1 Measuring the gap between the print head and platen	4
2-2 Adjusting the gap between the print head and platen	5
3. Adjusting the dot alignment	6
3-1 Adjustment A	6
3-2 Adjustment B	7
3-3 Adjusting the solenoid gap	8
3-4 Adjusting the cam position	9

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*