

CITIZEN

Service Manual

LINE THERMAL PRINTER
MODEL CT-S300

Rev. 1.00 Newly issued on Sep. 15, 2003

CONTENTS

INTRODUCTION	1
1. FEATURES	1
2. SPECIFICATIONS	2
3. DISASSEMBLY AND REASSEMBLY	3
3.1 Tools Used	3
3.2 Disassembly Procedure	4
3.2.1 Overall Disassembly	4
3.2.2 Disassembly of Mechanism Chassis Assembly	5
3.2.3 Disassembly of Platen Assembly	7
3.3 Reassembly Procedure	8
3.4 Lubrication	8
4. TROUBLESHOOTING	9
4.1 Troubleshooting Procedure	9
4.2 Troubleshooting Guide	9
5. SERVICE PARTS LIST	13
5.1 Parts List for Mechanism	13
5.2 Exploded View of Mechanism	14
5.3 Parts List for Electrical Parts	16
5.4 Main Board	17
6. CIRCUIT DIAGRAM	18
6.1 Main Board	18
6.2 Serial Interface	19
6.3 Parallel Interface	20
7. EXTERNAL VIEW	21

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*