


# **LINE THERMAL PRINTER**

## **MODEL CT-S310**

### **User's Manual**



**CITIZEN SYSTEMS JAPAN CO., LTD.**

# THE TABLE OF CONTENTS

---

<b>1. GENERAL OUTLINE</b> .....	<b>9</b>
1.1 Features .....	9
1.2 Unpacking .....	10
1.3 Model Classification .....	10
1.4 Basic Specifications .....	11
<b>2. EXPLANATION OF PRINTER PARTS</b> .....	<b>12</b>
2.1 Printer Appearance .....	12
2.2 Paper Cover Inside .....	14
2.3 Other Built-in Functions .....	14
<b>3. PREPARATION</b> .....	<b>15</b>
3.1 Connecting the AC Adapter and AC Power Cord .....	15
3.2 Connecting Interface Cables .....	16
3.3 Connecting the Cash Drawer .....	17
3.4 Installing the Printer .....	18
3.5 Partition for 58-mm Wide Paper Roll .....	18
3.6 Setting DIP Switch .....	19
3.7 Adjusting the Paper Near-end Sensor .....	20
<b>4. MAINTENANCE AND TROUBLESHOOTING</b> .....	<b>21</b>
4.1 Setting/Replacing Paper Rolls .....	21
4.2 Removing Jammed Paper .....	21
4.3 Cleaning the Print Head .....	22
4.4 When the Paper Cover Cannot Be Opened .....	22
4.5 Self-printing .....	23
4.6 Hexadecimal Dump Printing .....	23
4.7 Error Indication .....	24
<b>5. OTHER</b> .....	<b>25</b>
5.1 External Views and Dimensions .....	25
5.2 Manual Setting of Memory Switch .....	26
5.3 Printing Paper .....	28

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*