

CITIZEN

# Service Manual

MODEL **iDP-562**

Japan CBM Corporation  
Information Systems Div.

## Contents

1. External Appearance and Name of Each Part.....	3
2. Method of detaching Each Part .....	4
2.1. Detaching Printer Cover.....	4
2.2 Detaching Upper Case.....	4
2.3 Detaching Control Board .....	5
2.4 Detaching Power Source .....	7
2.5 Detaching Print Head .....	8
3. Circuit Composition .....	8
3.1 Interface Circuits.....	9
3.1.1 Parallel interface of iDP562-CNL.....	9
3.1.2 Serial Interface of iDP562-RSL and iDP562-RSL2 .....	10
3.2 Printer Head Signal .....	11
4. Circuit Diagram .....	16
4.2 Model IDP562-RSL .....	17
4.3 Model IDP562-RSL2 .....	18
5. Parts Position .....	19
5.1 IDP562-CNL Control PCB Parts Position .....	19
5.2 IDP562-RSL Control PCB Parts Position .....	20
5.3 IDP562-RSL2 Control PCB Parts Position .....	21
5.4 Power PCB Parts Position .....	22
5.5 Exploded View Model IDP562CNL/UL .....	23
5.6 Exploded View Model IDP562RSL, RSL2/UL .....	24
5.7 Exploded View Model IDP562CNL/EP.....	25
5.8 Exploded View Model IDP562RSL, RSL2/EP .....	26
6. Parts List.....	27
6.1 Printer DP575L-12A .....	27
6.2 IDP562-CNL, RSL, RSL2 .....	32

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*