

CITIZEN

Service Manual

MODEL **iDP-562**

Japan CBM Corporation
Information Systems Div.

Contents

1. External Appearance and Name of Each Part.....	3
2. Method of detaching Each Part	4
2.1. Detaching Printer Cover.....	4
2.2 Detaching Upper Case.....	4
2.3 Detaching Control Board	5
2.4 Detaching Power Source	7
2.5 Detaching Print Head	8
3. Circuit Composition	8
3.1 Interface Circuits.....	9
3.1.1 Parallel interface of iDP562-CNL.....	9
3.1.2 Serial Interface of iDP562-RSL and iDP562-RSL2	10
3.2 Printer Head Signal	11
4. Circuit Diagram	16
4.2 Model IDP562-RSL	17
4.3 Model IDP562-RSL2	18
5. Parts Position	19
5.1 IDP562-CNL Control PCB Parts Position	19
5.2 IDP562-RSL Control PCB Parts Position	20
5.3 IDP562-RSL2 Control PCB Parts Position	21
5.4 Power PCB Parts Position	22
5.5 Exploded View Model IDP562CNL/UL	23
5.6 Exploded View Model IDP562RSL, RSL2/UL	24
5.7 Exploded View Model IDP562CNL/EP.....	25
5.8 Exploded View Model IDP562RSL, RSL2/EP	26
6. Parts List.....	27
6.1 Printer DP575L-12A	27
6.2 IDP562-CNL, RSL, RSL2	32

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Citizen/iDP-562 service manual.html](https://the-checkout-tech.com/manuals/Citizen/iDP-562%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)