


TM-T88II Series

User's Manual

Printer Parts and Labels



Caution Labels



Thermal head is hot.



La tête thermique est chaude.



Der Thermalkopf ist heiß.



Caution label above for the drawer kick-out connector.

Labels



Label inside printer cover



Label inside cutter section

Quick Reference

This Quick Reference will direct you to key areas of this Operator's Manual. For a complete listing of topics, see the Contents.

Printer Parts and Labels *inside front cover*

Ordering Paper *page ix*

Where to order paper.

Setting Up the Printer *page 1-1*

How to set up the printer.

Installing and Replacing Paper *page 1-7*

How to load or change the paper roll.

Solving Problems *page 3-1*

How to correct problems.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)