

TM-T88IV

**Technical reference
guide**

English

410528700

EPSON

Contents

Chapter 1 **Product Overview**

Features	1-1
Product Structure	1-2
Model	1-2
Accessories.....	1-2
Options.....	1-2
Consumable products	1-2
TM-T88IV Basic Specification Table	1-3
Part Names and Basic Operation	1-3
Part Names	1-3
Control Panel.....	1-4
Power Switch.....	1-5
Connectors.....	1-5
Handling the Printer	1-5
Installing and Replacing Roll Paper	1-6
Removing Jammed Paper	1-7
Cleaning the Thermal Head	1-8
Power Switch Cover.....	1-9
Connector Cover.....	1-9
Shipping Procedures	1-10

Chapter 2 **Setup**

Installing the Printer.....	2-2
Precautions for Horizontal Installation.....	2-2
Precautions for Wall Installation	2-2
Setting the DIP Switches	2-2
DIP Switch Positions and Steps for Changing DIP Switch Settings	2-2
DIP Switch Functions.....	2-3
Customized value.....	2-6
Adjusting the Roll Paper Near-End Detector.....	2-6
Connecting the Printer to the Host Computer	2-8
Serial Interface Connection	2-8
Parallel Interface Connection	2-10
USB Interface Connection	2-11
Ethernet Interface Connection	2-13
Wireless LAN Interface Connection	2-15
Connecting Power Supply Unit and Cash Drawer	2-15
Connecting the Power Supply Unit.....	2-15
Connecting the Drawer Kick-out Cable	2-16
Installing the Driver.....	2-16

Chapter 3 **Application Development Information**

Introducing the Control Methods	3-1
Windows Driver (EPSON Advanced Printer Driver)	3-1
EPSON OPOS ADK	3-3
ESC/POS Commands	3-6
Various Utilities	3-6
Switches and Buttons	3-6
FEED Button	3-7
Panel LEDs and Error Status	3-7
(POWER) LED	3-7
PAPER OUT LED	3-7
Error LED	3-8
Sensors	3-10
Paper Sensors	3-10
Printer Cover Sensor	3-10
Offline	3-11
Busy State	3-11
NVRAM (Non-volatile Memory)	3-12
Bar Code Printing	3-12
Notes on Printing 2-Dimensional Code	3-13
Two-color printing	3-13
Operating Mode (Switch Panel Operation)	3-13
Self-test Mode	3-13
FAQ List	3-14
Q: Why has my print data dropped out?	3-14
Q: Why does the drawer kick-out not operate properly?	3-14
Q: I cannot print part of Page 0 in Visual Basic. Why?	3-15

Chapter 4 **ESC/POS Command-related Information**

NV Memory (Non-volatile Memory)	4-1
Using NV Memory	4-1
Printer Status	4-2
Precautions When the Printer Is Offline	4-2
Outputting Hex Dumps	4-2

Chapter 5 **Product Specifications**

Product Specifications (TM-T88IV)	5-1
Print Specifications (TM-T88IV)	5-2
Character Specifications (TM-T88IV)	5-3
Paper Specifications (TM-T88IV)	5-3
Printable Area (TM-T88IV)	5-4
Print Position versus Cutter Position (TM-88IV)	5-5
Overview of External Dimensions (TM-T88IV)	5-6
External Dimensions	5-6
Operating Specifications (TM-T88IV)	5-7

Appendix A **Interfaces and Connectors**

RS-232 Serial Interface	A-1
Interface Board Specifications (RS-232-compliant)	A-1
Functions of each Connector Pin	A-2
XON/XOFF	A-2
Code	A-3
IEEE 1284 Parallel Interface	A-3
Modes	A-3
Interface Signals	A-5

Appendix B Options and Consumables

Roll Paper.....	B-1
Power Supply	B-1
PS-180.....	B-1

Appendix C Character Code Tables

Page 0 (PC437: USA, Standard Europe)	C-1
Page 1 (Katakana).....	C-2
Page 2 (PC850: Multilingual)	C-3
Page 3 (PC860: Portuguese).....	C-4
Page 4 (PC863: Canadian-French)	C-5
Page 5 (PC865: Nordic)	C-6
Page 16 (WPC1252).....	C-7
Page 17 (PC866: Cyrillic #2).....	C-8
Page 18 (PC852: Latin2)	C-9
Page 19 (PC858: Euro)	C-10
Page 255 (Blank Page)	C-11
International Character Set	C-12

Appendix D TM-T88IV/TM-88III Comparison Table

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/Epson/TM-T88IV> technical reference manual.htm

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)