



**NCR 7167 Two-Station POS Printer
Release 2.0
Owner's Manual**



B005-000-1406
Revision E
July 2004

Contents

Quick Reference.....	v
How to Use this Book.....	vi
Who Should Use this Book?.....	vi
How to Obtain More Information.....	vi
Revision Record.....	vi
Contents	vii
Chapter 1: About the 7167 Printer	1
Features and Options.....	2
Receipt Station.....	2
Slip Station	2
Receipt and Slip Print Stations	3
General Features	3
Options	4
Thermal Print Head.....	5
Impact Print Head	5
Ordering Paper and Supplies.....	6
Ordering Thermal Receipt Paper.....	6
Ordering Ribbon Cassettes	7
Ordering Other Supplies.....	8
Ordering Documentation	8
Cleaning the Printer	9
Cleaning the Cabinet	9
Cleaning the Thermal Print Head	9
Cleaning the Scanner Sensor	9
Chapter 2: Setting Up and Using the Printer	11
What Is in the Box?.....	11
Removing the Packing Material	12
Re Packing the Printer.....	13
Choosing a Location	13
c) Wall mounted Power Supply (Option)	14
Setting Switches.....	15
Printer Reset	16
Using the Printer	19
Loading and Changing the Receipt Paper	20
Removing the Paper Roll.....	21
Loading the Paper Roll.....	22
Advancing Paper	23
Installing and Changing the Ribbon Cassette	23
Removing the Ribbon Cassette.....	23
Installing the Ribbon Cassette	24
Printing on Forms or Checks	25
Validating and Verifying Checks.....	27
About the Universal Serial Bus.....	29
Advantages of USB connections	29
Advantages of the NCR USB Solution.....	29
Checking for USB Support on the Host Computer	29
Host Configuration	30
Installing the USB Printer Drivers	31
Checking the Installation	41
Configuring Serial Port Number Assignments.....	44

Running the Edgeport Utility	45
Serial Port Configuration Methods.....	45
Uninstalling the Drivers.....	46
Chapter 3: Solving Problems	48
Green LED Does Not Come On/Printer Will Not Print	48
Green LED Blinking (Slow)	49
Green LED Blinking (Fast).....	49
Slip or Forms Printing is Light	50
Receipt Printing is Light or Spotty.....	51
LED (Slip Table) Does Not Come On	51
Forms Skew or Catch.....	51
MICR Check Reader Not Reading Properly	52
Other Serious Problems	52
Contacting a Service Representative.....	52
Chapter 4: Diagnostics.....	53
Level 0 Diagnostics.....	53
Level 1 Diagnostics.....	54
Printer Configuration.....	54
Configuring the Printer.....	56
Communication Interface Modes	58
Diagnostic Modes	61
Emulation/Software Options	66
Hardware Options.....	70
Default Code Page.....	74
Mfg Adjustment	77
Mfg Adjustment:	77
Level 2 Diagnostics.....	90
Level 3 Diagnostics.....	91
Chapter 5: Communication.....	75
Communication Overview	75
Interface.....	75
Sending Commands.....	75
RS-232C Interface	76
Print Speed and Timing	76
XON/XOFF Protocol.....	77
DTR/DSR Protocol.....	77
RS-232C Technical Specifications.....	78
RS-232C 9-Pin to 9-Pin Cable Diagram.....	78
Other Connector Information.....	79
USB Cable Connector	79
Power Cable Connector	79
Cash Drawer Connector and Pin Assignments	80
Setting Extra RS-232C Options.....	83
Chapter 6: Commands.....	85
Introduction.....	85
List of Commands and Location	85
By Command Code	86
Printer Function Commands.....	92
Vertical Positioning and Print.....	93
Horizontal Positioning Commands.....	94
Print Characteristic Commands	95
Graphics Commands	96
Status Commands	96

Real Time Commands	97
Unsolicited Status Update	97
Bar Code Commands.....	97
Macro Commands	98
MICR Check Reader Commands	98
MICR Parsing.....	98
User Data Storage Commands.....	99
Asian Character Commands	99
Scanner Function Commands.....	100
Flash Download Commands.....	101
Printer Function Commands.....	105
Vertical Positioning and Print Commands.....	120
Horizontal Positioning Commands.....	129
Print Characteristic Commands	136
Graphics Commands	156
Status Commands	165
Transmit Printer ID, Remote Diagnostics Extension	169
Real Time Commands	178
Unsolicited Status Update Validation.....	186
Bar Code Commands.....	192
Page Mode Commands.....	198
Macro Commands	206
MICR Commands.....	208
MICR Parsing.....	209
Check Flip Command.....	220
User Data Storage Commands.....	220
Asian Character Commands	229
Scanner Function Commands.....	233
Flash Download Commands.....	257
Appendix A: Specifications	264
Printing Specifications	264
Power Requirements	265
Environmental Conditions	265
Reliability.....	266
Dimensions and Weight.....	266
Density of Receipt Print Lines	266
Duty Cycle Restrictions (Printing Solid Blocks)	267
Appendix B: Print Characteristics	268
Character Size	268
Receipt Station.....	268
Slip Station	269
Print Zones.....	272
Receipt Station.....	272
Slip Station	273
Slip Form Parameters	275
Check Size	276
MICR Media Requirements.....	276
Appendix C: Character Sets	277
Appendix D: RS485 Interface	331
General.....	331
Basic Printer Functions.....	331
Command List	333
Command and Status Descriptions.....	344

Printer Command Details	346
Diagnostics.....	363
Diagnostics Overview	363
Startup (Level 0) Diagnostics	364
Level 2 Diagnostics	365
Configuring the Printer For RS485 (Level 1).....	366
Index.....	385

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/NCR/7167_owners_manual.html

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)