



# **NCR 7193 Thermal Receipt Printer**

## Owner's Guide

BD20-1439-A  
Issue B  
August 1998

# Contents

<b>Chapter 1: About the 7193 Printer</b>	<b>1</b>
Models .....	1
Communication Interfaces.....	1
Features .....	2
Options .....	2
Thermal Printhead .....	2
Ordering Thermal Paper .....	3
Ordering Other Supplies.....	3
Cleaning the Printer .....	4
Cleaning the Cabinet .....	4
Cleaning the Thermal Printhead.....	4
<b>Chapter 2: Setting Up the Printer</b>	<b>5</b>
What Is in the Box? .....	5
Removing the Printer .....	5
Repacking the Printer .....	6
Choosing a Location .....	6
Setting Switches.....	6
Connecting Cash Drawer Cables .....	8
Connecting Communication and Power Cables .....	9
RS-232C Models .....	9
Parallel Models.....	10
Turning On the Printer .....	11
Loading and Changing Paper.....	12
When to Change the Paper .....	12
Removing the Paper Roll .....	12
Putting In the Paper Roll.....	13
Advancing Paper.....	14
Clearing Paper Jams .....	14
Testing the Printer.....	15
Mounting the Printer on a Wall.....	17
Mounting the Power Supply on a Wall.....	19
<b>Chapter 3: Solving Problems</b>	<b>21</b>
Operator Panel Lights.....	21
Correcting Problems .....	22
Operator-Correctable Conditions .....	22
Service-Related Problems .....	22
Contacting a Service Representative .....	23

<b>Chapter 4: Diagnostics</b>	<b>25</b>
Level 0 Diagnostics.....	25
Level 1 Diagnostics.....	26
Setting Data Error and Data Buffer options.....	26
Setting Printhead Resistance.....	27
Setting Default Lines per Inch.....	28
Setting Partial Cut Distance.....	28
Ignoring/Using the Carriage Return.....	29
Running the Data Scope Mode.....	30
Testing Receipt Printing.....	31
Level 2 Diagnostics.....	32
Level 3 Diagnostics.....	32
<b>Chapter 5: Communication</b>	<b>33</b>
Communication Overview.....	33
Interfaces.....	33
Sending Commands.....	33
RS-232C Interface.....	34
Print Speed and Timing.....	34
XON/XOFF Protocol.....	35
DTR/DSR Protocol.....	35
RS-232C Technical Specifications.....	36
Parallel Interface.....	39
Parallel Protocol.....	39
Parallel Technical Specifications.....	40
<b>Chapter 6: Commands</b>	<b>43</b>
Command List.....	43
Printer Function Commands.....	43
Print Characteristics Commands.....	45
Graphics Commands.....	45
Printer Status Commands.....	46
Real Time Commands.....	46
Bar Code Commands.....	46
Command Descriptions.....	47
Printer Function Commands.....	47
Print Characteristics Commands.....	56
Graphics Commands.....	60
Printer Status Commands.....	63
Real Time Commands.....	70
Bar Code Commands.....	77

<b>Appendix A: Specifications</b>	<b>81</b>
Features .....	81
Reliability .....	81
Power Requirements.....	81
Environmental Conditions.....	82
Dimensions and Weight.....	82
Printing Specifications.....	82
Print Zones.....	83
Density of Receipt Print Lines .....	84
Duty Cycle Restrictions (Printing Solid Blocks).....	84
<b>Appendix B: Print Characteristics</b>	<b>85</b>
Character Size .....	85
Code Page 437 Character Set .....	86
Code Page 850 Character Set .....	87
<b>Index</b>	<b>89</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*