

# SRP-270 SERIES



---

## 1 STATION PRINTER

### Operator's Manual

All specifications are subjected to change without notice

# Table of Contents

<b>CHAPTER 1. UNPACKING .....</b>	<b>4</b>
1-1. CHECKING THE CONTENTS OF THE PRINTER BOX.....	4
1-2. LOCATING THE PRINTER .....	4
1-3. FUNCTIONS.....	5
<b>CHAPTER 2. CONNECTING THE CABLES .....</b>	<b>6</b>
2-1. CONNECTING THE AC ADAPTER TO THE PRINTER.....	6
2-2. CONNECTING INTERFACE CABLE AND DRAWER .....	7
<b>CHAPTER 3. INSTALLING THE ROLL PAPER.....</b>	<b>8</b>
3-1. RIBBON CASSETTE INSTALLATION .....	8
3-2. ROLL PAPER INSTALLATION.....	9
<b>CHAPTER 4. SETTING THE DIP SWITCHES.....</b>	<b>13</b>
<b>CHAPTER 5. HEXADECIMAL DUMPING.....</b>	<b>16</b>
<b>CHAPTER 6. THE SELF TEST .....</b>	<b>17</b>
<b>CHAPTER 7. CODE TABLE .....</b>	<b>18</b>
<b>CHAPTER 8. CONTROL COMMANDS LIST .....</b>	<b>25</b>
<b>APPENDIX A .....</b>	<b>29</b>
CONNECTORS .....	29
<i>Interface Connector</i> .....	30
<i>Drawer Connector</i> .....	32
<b>APPENDIX B .....</b>	<b>33</b>
SPECIFICATION .....	33
<b>APPENDIX C .....</b>	<b>34</b>
REMOVING JAMMED PAPER .....	34

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*