




USER'S MANUAL

SRP-370/372

THERMAL RECEIPT PRINTER



All specifications are subjected to change without notice
<http://www.samsungminiprinters.com>

Safety Precautions

In using the present appliance, please keep the following safety regulations in order to prevent any hazard or material damage.









 WARNING Violating following instructions can cause serious injury or death.	
<p>Do not plug several products in one multi-outlet.</p> <ul style="list-style-type: none"> • This can provoke over-heating and a fire. • If the plug is wet or dirty, dry or wipe it before usage. • If the plug does not fit perfectly with the outlet, do not plug in. • Be sure to use only standardized multi-outlets. <p>PROHIBITED</p> 	<p>You must use only the supplied adapter.</p> <ul style="list-style-type: none"> • It is dangerous to use other adapters. 
<p>Do not pull the cable to unplug.</p> <ul style="list-style-type: none"> • This can damage the cable, which is the origin of a fire or a breakdown of the printer. <p>PROHIBITED</p> 	<p>Keep the plastic bag out of children's reach.</p> <ul style="list-style-type: none"> • If not, a child may put the bag on his head. <p>PROHIBITED</p> 
<p>Do not plug in or unplug with your hands wet.</p> <ul style="list-style-type: none"> • You can be electrocuted. <p>PROHIBITED</p> 	<p>If you observe a strange smoke, odor or noise from the printer, unplug it before taking following measures.</p> <ul style="list-style-type: none"> • Switch off the printer and unplug the set from the mains. • After the disappearance of the smoke, call your dealer to repair it.
<p>Do not bend the cable by force or leave it under any heavy object.</p> <ul style="list-style-type: none"> • A damaged cable can cause a fire. <p>PROHIBITED</p> 	<p>TO UNPLUG</p> 


Table of Contents

CHAPTER 1. SETTING UP THE PRINTER	5
1-1. UNPACKING	5
1-2. CONNECTING THE CABLES	6
1-3. CONNECTING THE COMPUTER	7
1-4. CONNECTING THE DRAWER	7
1-5. CONNECTING THE POWER SUPPLY	8
1-6. INSTALLING OR REPLACING THE PAPER ROLL	9
1-7. ADJUSTMENTS AND SETTINGS	11
1-8. USING THE PRINTER.....	12
1-9. SETTING THE DIP SWITCHES	13
1-10. SETTING THE MEMORY SWITCHES.....	15
 CHAPTER 2. HEXADECIMAL DUMPING	 17
CHAPTER 3. THE SELF TEST	18
CHAPTER 4. CODE TABLE.....	19
CHAPTER 5. CONTROL COMMANDS LIST.....	36
 APPENDIX	 84
A. CONNECTORS	84
RS-232C Cable Connector	85
Interface Connector.....	85
Drawer Connector	87
B. NOTES	87
C. SPECIFICATION	88


Chapter 1. Setting Up the Printer

1-1. Unpacking


Your printer box should include these items. If any items are damaged or missing, please contact your dealer for assistance.



SRP-370/372



Cover Cable



Roll Paper



Operator's manual



AC Adapter



Power Code

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Samsung/SRP-370 SRP-372 user manual.html](https://the-checkout-tech.com/manuals/Samsung/SRP-370%20SRP-372%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)