

# SHARP SERVICE MANUAL

CODE: 00ZER04RPSM-E

## Remote Printer

### MODEL ER-04RP

OPTION FOR IN LINE SYSTEM

#### CONTENTS

1. General .....	1
2. Specifications .....	1
3. Setting of Dip switches .....	2
4. Disassembly procedure .....	3
5. Circuit description .....	5
6. Printer unit description .....	9
7. Auto cutter unit .....	10
8. Overview and operating principle of the printer .....	14
9. Troubleshooting .....	18
10. Disassembly and reassembly .....	22
11. Test Function (SW1-7: ON) .....	34
12. Special service tool .....	35
13. Circuit diagram .....	37
14. Installation procedure of in-line cable .....	43
15. Installation procedure of ER-04RP for mounqing on a wall .....	43

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)