


TEC

TEC Portable Printer

B-210 SERIES

Owner's Manual

Document No. **EM1-33043D**



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

	Page
1. INTRODUCTION	1-1
1.1 APPLICABLE MODEL	1-10
1.2 ACCESSORIES	1-11
2. SPECIFICATIONS	2-1
2.1 PRINTER	2-1
2.2 SERIAL INTERFACE (RS-232C)	2-2
2.3 RADIO INTERFACE	2-2
2.4 IrDA INTERFACE	2-3
2.5 MEDIA	2-4
3. APPEARANCE	3-1
3.1 FRONT/REAR VIEW	3-1
3.2 OPERATION PANEL	3-2
4. INSTALLING THE PRINTER	4-1
4.1 LOADING THE BATTERY	4-1
4.2 INSTALLING THE MEDIA GUIDE	4-3
5. LOADING THE MEDIA	5-1
6. SECURING THE PRINTER TO YOUR WAIST	6-1
7. ISSUING THE MEDIA	7-1
8. CARE/HANDLING OF THE MEDIA	8-1

	Page
9. GENERAL MAINTENANCE	9-1
9.1 CLEANING	9-1
9.2 COVERS AND OPERATION PANEL	9-3
9.3 REMOVING JAMMED MEDIA	9-4
10. TROUBLESHOOTING	10-1

CAUTION:

- 1. This manual may not be copied in whole or in part without the prior written permission of TEC.*
- 2. The contents of this manual may be changed without notification.*
- 3. Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

Copyright © 1997
by TEC CORPORATION
All Rights Reserved
570 Ohito, Ohito-cho, Tagata-gun, Shizuoka-ken, JAPAN

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/TEC/B-210_owners_manual.html

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)