


TEC

TEC Bar Code Printer

B-411 SERIES

Owner's Manual



TOKYO ELECTRIC CO., LTD.

TABLE OF CONTENTS

	Page
INTRODUCTION	1
PRECAUTIONS	1
APPLICABLE MODEL	1
1. SPECIFICATIONS	2
1.1 PRINTER	2
1.2 PAPERS	2
1.3 INTERFACE	2
1.4 BATTERY CHARGER	3
1.5 DIMENSIONS	3
2. OVERVIEW	4
2.1 FRONT VIEW	4
2.2 REAR VIEW	4
2.3 OPERATION PANEL	5
3. INSTALLING THE PRINTER	5
3.1 HOW TO INSTALLING AND ADJUST THE SHOULDER STRAP	5
3.2 REPLACING AND INSTALLING THE BATTERY	6
3.3 CHARGING THE BATTERY	6
4. LOADING PAPERS	7
5. REMOVING THE JAMMED PAPERS	9
6. CLEANING	10
6.1 THERMAL HEAD/PLATEN/PINCH ROLLER	10
6.2 COVERS/PANELS	10
7. SELECTING A DATA TRANSMISSION SPEED	11
8. TROUBLESHOOTING	12

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/TEC/B-411 series owners manual.html](https://the-checkout-tech.com/manuals/TEC/B-411%20series%20owners%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)