




TEC Portable Printer

B-415 SERIES

Owner's Manual



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

	Page
1. INTRODUCTION	E1-1
1.1 Applicable Model	E1-1
1.2 Accessories	E1-1
2. SPECIFICATION	E2-1
2.1 Printer	E2-1
2.2 IrDA Interface	E2-1
2.3 Serial Interface (RS-232C) (for GH24 and GH34 models)	E2-2
2.4 Radio Interface (for GH34 model)	E2-2
2.5 Bluetooth Interface (for GH25 model)	E2-2
2.6 External DC Input	E2-3
2.7 Battery	E2-3
2.8 Option	E2-3
2.9 Media	E2-4
3. APPEARANCE	E3-1
3.1 Front/Rear View	E3-1
3.2 Description of LED Lamp	E3-1
3.3 Description of Switch/Button	E3-1
4. LOADING AND REMOVING THE BATTERY	E4-1
5. ATTACHING THE SHOULDER STRAP	E5-1
6. SET UP PROCEDURE	E6-1
6.1 Requirements for Operation	E6-1
7. LOADING THE LABEL	E7-1
7.1 How to Load the Liner Backed Label Roll	E7-1
7.2 How to Load the Linerless Label Roll	E7-3
8. ISSUING THE MEDIA	E8-1
9. SELF-DIAGNOSTIC TEST PRINT	E9-1
10. CARE/HANDLING OF THE MEDIA	E10-1
11. GENERAL MAINTENANCE	E11-1
11.1 Cleaning	E11-1
11.2 Covers and Operation Panel	E11-2
11.3 Removing Jammed Media	E11-2
12. LED DISPLAY AND TROUBLESHOOTING	E12-1
13. ERROR PROCESS	E13-1

CAUTION:

1. *This manual may not be copied in whole or in part without prior written permission of TOSHIBA TEC.*
2. *The contents of this manual may be changed without notification.*
3. *Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*