

TEC High Speed PC Interface Kit B-4800-PC-QM

Owner's Manual

•

TABLE OF CONTENTS

EM1-39013

and a second

			Page
1.	. INT	RODUCTION	1- 1
	1.1	Precaution	1-1
	1.2	Accessories	1- 1
•			1- 1
2.		CIFICATIONS	2-1
	2.1	Printer Drivers (1.44 MB formatted)	2-1
	2.2	BPC PC Board	2-1
З.	INST		3- 1
	SETUP		
	4.1	Sotup of the Windows Data and	4- 1
	·••. 1	Setup of the Windows Drivers	4-1
		4.1.1 Installing the Driver	4-2
•		4.1.2 High Speed PC Interface/Centronics Selection	4- 6
	4.2	Setup of the Printer	4-8
	4.3	Print Manager Setup	4-12
	4.4	Printer Command Transmission	4-13
	4.5	Driver Registration Deletion	4-18
	4.6	MS-DOS Driver Installation	4-19
_			
	EKK	OR MESSAGE	5- 1
	5.1	High Speed PC Interface	5- 1
	5.2	Centronics Interface	5- 7

CAUTION:

1. This manual may not be copied in whole or in part without the prior written permission of TEC.

Copyright () 1994 by Tokyo Electric Co., Lid.

2. The contents of this manual may be changed without notification.

3. Please refer to your local Authorized Service representative with regard to questions.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store: https://the-checkout-tech.com/manuals/TEC/B-4800-PC-QM owners manual.html

And our free Online Keysheet maker: https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM