



TOSHIBA TEC Bar Code Printer

**B-482-QQ/QP, B-882-QQ/QP, B-682-QQ/QP**

**External Equipment Interface Specification**

First Edition: June 25, 1999  
Second Edition: July 28, 1999  
Third Edition: October 26, 1999  
Fourth Edition: March 21, 2000

**TOSHIBA TEC CORPORATION**

# TABLE OF CONTENTS

|   | Page      |
|---|-----------|
| <b>1. SCOPE.....</b>                                    | <b>1</b>  |
| <b>2. GENERAL DESCRIPTION .....</b>                     | <b>1</b>  |
| <b>3. INTERFACE.....</b>                                | <b>2</b>  |
| 3.1 SERIAL INTERFACE .....                              | 2         |
| 3.2 PARALLEL INTERFACE.....                             | 7         |
| 3.3 NETWORK ITNERFACE .....                             | 13        |
| <b>4. KEY OPERATION FUNCTIONS .....</b>                 | <b>14</b> |
| 4.1 SYSTEM MODE FUNCTIONS.....                          | 14        |
| 4.2 ON-LINE MODE FUNCTIONS.....                         | 18        |
| 4.3 DOWNLOAD MODE SETTING FUNCTION.....                 | 18        |
| <b>5. TRANSMISSION SEQUENCE.....</b>                    | <b>19</b> |
| 5.1 INITIALIZATION.....                                 | 19        |
| 5.2 LABEL ISSUE OPERATION .....                         | 21        |
| <b>6. INTERFACE COMMANDS .....</b>                      | <b>23</b> |
| 6.1 OUTLINE OF COMMANDS .....                           | 23        |
| 6.2 LIST OF COMMANDS .....                              | 24        |
| 6.3 LABEL SIZE SET COMMAND .....                        | 25        |
| 6.4 POSITION FINE ADJUST COMMAND.....                   | 30        |
| 6.5 PRINT DENSITY FINE ADJUST COMMAND.....              | 36        |
| 6.6 RIBBON MOTOR DRIVE VOLTAGE FINE ADJUST COMMAND..... | 37        |
| 6.7 IMAGE BUFFER CLEAR COMMAND .....                    | 38        |
| 6.8 CLEAR AREA COMMAND.....                             | 39        |
| 6.9 LINE FORMAT COMMAND .....                           | 41        |
| 6.10 BIT MAP FONT FORMAT COMMAND.....                   | 45        |
| 6.11 OUTLINE FONT FORMAT COMMAND .....                  | 58        |
| 6.12 BAR CODE FORMAT COMMAND .....                      | 75        |
| 6.13 BIT MAP FONT DATA COMMAND .....                    | 108       |
| 6.14 OUTLINE FONT DATA COMMAND .....                    | 111       |
| 6.15 BAR CODE DATA COMMAND.....                         | 114       |
| 6.16 ISSUE COMMAND.....                                 | 127       |
| 6.17 FEED COMMAND.....                                  | 141       |
| 6.18 EJECT COMMAND.....                                 | 147       |
| 6.19 FORWARD/REVERSE FEED COMMAND.....                  | 148       |
| 6.20 STORAGE AREA ALLOCATE COMMAND .....                | 150       |
| 6.21 MEMORY CARD FORMAT COMMAND.....                    | 152       |
| 6.22 2-BYTE WRITABLE CHARACTER CODE RANGE COMMAND ..... | 153       |
| 6.23 BIT MAP WRITABLE CHARACTER COMMAND.....            | 154       |
| 6.24 GRAPHIC COMMAND.....                               | 165       |

|  | Page       |
|--|------------|
| 6.25 SAVE START COMMAND.....   | 173        |
| 6.26 SAVE TERMINATE COMMAND.....   | 175        |
| 6.27 SAVED DATA CALL COMMAND .....                                       | 176        |
| 6.28 HEAD BROKEN DOTS CHECK COMMAND .....                                | 177        |
| 6.29 MESSAGE DISPLAY COMMAND .....                                       | 178        |
| 6.30 RESET COMMAND .....   | 180        |
| 6.31 STATUS REQUEST COMMAND.....   | 181        |
| 6.32 VERSION INFORMATION ACQUIRE COMMAND .....                           | 182        |
| 6.33 ATA CARD INFORMATION ACQUIRE COMMAND .....                          | 183        |
| 6.34 ATA CARD WRITABLE CHARACTER INFORMATION ACQUIRE COMMAND .....       | 185        |
| 6.35 IP ADDRESS SET COMMAND .....  | 186        |
| <br>   |            |
| <b>7. CONTROL CODE SELECTION .....</b>                                   | <b>187</b> |
| <br>   |            |
| <b>8. ERROR PROCESSING .....</b>   | <b>188</b> |
| 8.1 COMMUNICATION ERRORS.....  | 188        |
| 8.2 ERRORS IN ISSUING OR FEEDING .....                                   | 188        |
| 8.3 ERRORS IN WRITABLE CHARACTER AND PC COMMAND ENTRY MODES .....        | 191        |
| 8.4 SYSTEM ERRORS .....  | 191        |
| 8.5 RESET PROCESSING .....   | 191        |
| <br>   |            |
| <b>9. STATUS RESPONSE .....</b>  | <b>192</b> |
| 9.1 SERIAL INTERFACE .....   | 192        |
| 9.1.1 Functions.....   | 192        |
| 9.1.2 Status Format .....  | 192        |
| 9.1.3 Detail Status.....   | 193        |
| 9.2 PARALLEL INTERFACE.....  | 195        |
| <br>   |            |
| <b>10. LCD MESSAGES AND LED INDICATIONS .....</b>                        | <b>197</b> |
| <br>   |            |
| <b>11. LCD MESSAGES IN DIFFERENT LANGUAGES.....</b>                      | <b>200</b> |
| <br>   |            |
| <b>12. CHARACTER CODE TABLE .....</b>                                    | <b>204</b> |
| 12.1 TIMES ROMAN, HELVETICA, LETTER GOTHIC, PRESTIGE ELITE, COURIER..... | 204        |
| 12.2 PRESENTATION .....  | 211        |
| 12.3 OCR-A.....  | 215        |
| 12.4 OCR-B.....  | 219        |
| 12.5 TEC OUTLINE FONT 1 .....  | 222        |
| 12.6 PRICE FONT 1, 2, 3 .....  | 229        |
| 12.7 TEC OUTLINE FONT 2, 3 .....   | 230        |
| 12.8 TrueType FONT .....   | 237        |

|   | Page |
|---|------|
| 13. BAR CODE TABLE .....                      | 244  |
| 14. DRAWING OF BAR CODE DATA.....             | 257  |
| 15. AUTOMATIC ADDING OF START/STOP CODE ..... | 278  |

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/TEC/B-482 and B-682 and B-882 Interface Spec](https://the-checkout-tech.com/manuals/TEC/B-482%20and%20B-682%20and%20B-882%20Interface%20Spec)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://the-checkout-tech.com)