




TEC Thermal Printer

B-670/680-QQ SERIES

Owner's Manual



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

| | Page |
|--|--------------|
| 1. INTRODUCTION | 1- 1 |
| 1.1 APPLICABLE MODEL | 1- 1 |
| 1.2 ACCESSORIES | 1- 1 |
| 2. SPECIFICATIONS | 2- 1 |
| 2.1 PRINTER | 2- 1 |
| 2.2 OPTIONS | 2- 2 |
| 2.3 MEDIA | 2- 3 |
| 2.4 RIBBON | 2- 3 |
| 3. OVERVIEW | 3- 1 |
| 3.1 FRONT/REAR VIEW | 3- 1 |
| 3.2 OPERATION PANEL | 3- 1 |
| 4. DIP SWITCH FUNCTIONS | 4- 1 |
| 5. SET UP PROCEDURE | 5- 1 |
| 5.1 REQUIREMENTS FOR OPERATION | 5- 1 |
| 5.2 SETTING UP THE PRINTER | 5- 1 |
| 6. INSTALLING THE PRINTER | 6- 1 |
| 6.1 CONNECTING THE POWER CORD AND CABLES | 6- 1 |
| 6.2 HOLDER STAND INSTALLATION | 6- 1 |
| 7. LOADING THE RIBBON | 7- 1 |
| 8. LOADING THE MEDIA | 8- 1 |
| 9. INSERTING THE OPTIONAL FLASH MEMORY CARD | 9- 1 |
| 10. INSERTING THE OPTIONAL PCMCIA CARD | 10- 1 |
| 11. CARE/HANDLING OF THE MEDIA AND RIBBON | 11- 1 |
| 12. GENERAL MAINTENANCE | 12- 1 |
| 12.1 CLEANING | 12- 1 |
| 12.2 UNDER THE MEDIA GUIDES | 12- 3 |
| 12.3 COVERS AND PANELS | 12- 3 |
| 12.4 REMOVING JAMMED MEDIA | 12- 4 |
| 12.5 THRESHOLD SETTING | 12- 6 |
| 13. TROUBLESHOOTING | 13- 1 |

CAUTION:

1. *This manual may not be copied in whole or in part without prior written permission of TOSHIBA TEC.*
2. *The contents of this manual may be changed without notification.*
3. *Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*