

# TOSHIBA

TOSHIBA Thermal Printer

## B-SA4TM SERIES

### Owner's Manual



## TABLE OF CONTENTS

	Page
<b>1. PRODUCT OVERVIEW.....</b>	<b>E1- 1</b>
1.1 Introduction.....	E1- 1
1.2 Features .....	E1- 1
1.3 Accessories .....	E1- 2
1.4 Appearance .....	E1- 3
1.4.1 Dimensions.....	E1- 3
1.4.2 Front View .....	E1- 3
1.4.3 Rear View.....	E1- 3
1.4.4 Operation Panel.....	E1- 4
1.4.5 Interior .....	E1- 4
1.5 Options.....	E1- 5
<b>2. PRINTER SETUP .....</b>	<b>E2- 1</b>
2.1 Installation .....	E2- 2
2.1.1 Attaching the Printer Rear Support.....	E2- 2
2.2 Connecting the Power Cord .....	E2- 2
2.3 Loading the Media .....	E2- 3
2.4 Loading the Ribbon .....	E2-11
2.5 Connecting the Printer to Your Host Computer .....	E2-14
2.6 Turning the Printer ON .....	E2-15
2.7 Setting an Operating Environment .....	E2-16
2.7.1 How to Enter the System Mode.....	E2-17
2.7.2 Parameter Setting.....	E2-17
2.7.3 IP Address Setting (TCP/IP).....	E2-24
2.8 Installing the Printer Drivers .....	E2-30
2.8.1 Introduction.....	E2-30
2.8.2 General Description.....	E2-30
2.8.3 Installing the Printer Driver .....	E2-31
2.8.4 Uninstalling the Printer Driver .....	E2-43
2.8.5 Adding/Deleting a LAN Port.....	E2-44
2.8.6 Cautions .....	E2-46
2.8.7 Using the Printer Driver .....	E2-47
2.9 Print Test .....	E2-48
2.10 Position and Print Tone Fine Adjustment .....	E2-50
2.11 Threshold Setting .....	E2-59
<b>3. ON LINE OPERATION .....</b>	<b>E3- 1</b>
3.1 Operation Panel.....	E3- 1
3.2 Operation.....	E3- 2
3.3 Reset .....	E3- 2
<b>4. MAINTENANCE .....</b>	<b>E4- 1</b>
4.1 Cleaning .....	E4- 1
4.1.1 Print Head/Platen/Sensors .....	E4- 1
4.1.2 Covers and Panels .....	E4- 2
4.1.3 Optional Cutter Module.....	E4- 3
4.1.4 Optional Strip Module .....	E4- 4

<b>5. TROUBLESHOOTING</b> .....	<b>E5- 1</b>
5.1 Error Messages.....	E5- 1
5.2 Possible Problems .....	E5- 3
5.3 Removing Jammed Media.....	E5- 4
<b>6. PRINTER SPECIFICATIONS</b> .....	<b>E6- 1</b>
<b>7. SUPPLY SPECIFICATIONS</b> .....	<b>E7- 1</b>
7.1 Media.....	E7- 1
7.1.1 Media Type .....	E7- 1
7.1.2 Detection Area of the Transmissive Sensor.....	E7- 2
7.1.3 Detection Area of the Reflective Sensor.....	E7- 3
7.1.4 Effective Print Area.....	E7- 3
7.2 Ribbon .....	E7- 4
7.3 Recommended Media and Ribbon Types .....	E7- 4
7.4 Care/Handling of Media and Ribbon.....	E7- 5
<b>APPENDIX 1 MESSAGES AND LEDS</b> .....	<b>EA1-1</b>
<b>APPENDIX 2 INTERFACE</b> .....	<b>EA2-1</b>
<b>APPENDIX 3 POWER CORD</b> .....	<b>EA3-1</b>
<b>APPENDIX 4 PRINT SAMPLES</b> .....	<b>EA4-1</b>
<b>APPENDIX 5 GLOSSARIES</b> .....	<b>EA5-1</b>
<b>INDEX</b>	

**WARNING!**

*This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.*

**CAUTION!**

1. *This manual may not be copied in whole or in part without prior written permission of TOSHIBA TEC.*
2. *The contents of this manual may be changed without notification.*
3. *Please refer to your local Authorised Service representative with regard to any queries you may have in this manual.*

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/TEC/B-SA4TM series owners manual.html](https://the-checkout-tech.com/manuals/TEC/B-SA4TM%20series%20owners%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)