TEC B-SP2D series owners Manual



TEC Portable Printer

B-SP2D SERIES

Owner's Manual



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

			Page
1.	INTE	ODUCTION	1-1
	1.1 1.2	APPLICABLE MODEL	
2.	SPECIFICATIONS		2-1
	2.1	PRINTER	
	2.2	SERIAL INTERFACE (RS-232C)	
	2.3	BLUETOOTHINTERFACE	
	2.4	WIRELESS LAN INTERFACE	_
	2.5	BATTERY	
	2.7		
3.	APF	PEARANCE	3-1
	3.1	FRONT VIEW	3-1
	3.2	INTERIOR	3-2
	3.3	OPERATION PANEL	3-2
4.	INSTALLING THE PRINTER		4-1
	4.1	LOADING THE BATTERY	4-1
	4.2	INSTALLING THE MEDIA GUIDE	4-3
	4.3	INSTALLING THE MEDIA GUIDE FOR OUTSIDE WOUND PAPER	4-5
5.	LOA	ADING THE MEDIA	5-1
6	SEC	CURING THE PRINTER TO YOUR WAIST	6-1

7.	CONNECTING THE SERIAL INTERFACE CABLE	7-1
8.	ISSUING THE MEDIA	8-1
9.	CARE/HANDLING OF THE MEDIA	9-1
10.	GENERAL MAINTENANCE	10-1
	10.1 CLEANING	
	10.2 COVERS	
	10.3 REMOVING JAMMED MEDIA	10-3
11.	TROUBLESHOOTING	11-1

CAUTION!

- 1. This manual may not be copied in whole or in part without the prior written permission of TOSHIBA TEC.
- 2. The contents of this manual may be changed without notification.
- 3. Please refer to your local Authorised Service representative with regard to any queries you may have in this manual.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/TEC/B-SP2D series owners manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM