




TEC Ink Jet Printer

BRST-10 SERIES

Owner's Manual



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

	Page
1. INTRODUCTION	1- 1
1.1 APPLICABLE MODEL	1- 1
1.2 ACCESSORIES	1- 1
2. SPECIFICATIONS	2- 1
2.1 PRINTER	2- 1
2.2 RECEIPT PAPER	2- 2
2.3 SLIP	2- 2
3. OVERVIEW	3- 1
3.1 FRONT/REAR VIEW	3- 1
3.2 OPERATION PANEL	3- 2
4. SET UP PROCEDURE	4- 1
4.1 REQUIREMENTS FOR OPERATION	4- 1
4.2 SETTING UP THE PRINTER	4- 1
5. INSTALLATION PROCEDURE	5- 1
5.1 CONNECTING THE POWER CORD AND CABLES	5- 1
5.2 LOADING THE HEAD UNIT/ INK CARTRIDGE	5- 2
5.3 LOADING THE RECEIPT ROLL	5- 4
5.4 INSERTING THE SLIP	5- 6
6. REPLACING THE RECEIPT ROLL	6- 1
7. REPLACING THE INK CARTRIDGE	7- 1
8. REPLACING THE HEAD UNIT/ INK CARTRIDGE	8- 1
9. GENERAL MAINTENANCE	9- 1
9.1 CLEANING	9- 1
9.2 REMOVING JAMMED PAPER	9- 1
10. TROUBLESHOOTING	10- 1
11. ERROR MESSAGE	11- 1

CAUTION:

1. *This manual may not be copied in whole or in part without prior written permission of TOSHIBA TEC.*
2. *The contents of this manual may be changed without notification.*
3. *Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*