




TEC Color Printer

**CB-416-T3-QQ**

**Owner's Manual**



**TOSHIBA TEC CORPORATION**

# Table of Contents

<b>1. Product Overview .....</b>	<b>1</b>
1.1 Introduction .....	1
1.2 Features .....	1
1.3 Unpacking .....	1
1.4 Accessories and Options .....	2
1.4.1 Accessories .....	2
1.4.2 Cool Release Enhancement Kit .....	3
1.4.3 Options .....	3
1.5 Appearance .....	4
1.5.1 Dimensions .....	4
1.5.2 Front View .....	4
1.5.3 Rear View .....	4
1.5.4 Operation Panel .....	5
1.5.5 Interior .....	5
<b>2. Printer Installation .....</b>	<b>6</b>
2.1 Installing the Accessories .....	6
2.1.1 Fan Filters .....	6
2.1.2 Media Slide .....	6
2.1.3 Supply Shaft Holder .....	6
2.2 Connecting the Printer to Your Computer .....	7
2.3 Connecting the Power Cord .....	8
2.4 Turning on/off the Printer .....	9
2.4.1 Turning on the Printer .....	9
2.4.2 Turning off the Printer .....	10
2.5 Loading the Media .....	11
2.5.1 Additional Information .....	16
2.6 Sensor Adjustments .....	17
2.6.1 Black Mark Sensor .....	17
2.6.2 Feed Gap Sensor .....	18
2.6.3 Media Sensor Sensitivity Adjustment .....	19
2.7 Loading the Ribbons (for Hot Release Ribbons) .....	21
2.7.1 Ribbon Positions .....	21
2.7.2 Loading Procedure .....	21
2.8 Loading the Ribbons (for Cold Release Ribbons) .....	24
2.8.1 Precautions .....	24
2.8.2 Installing the Ribbon Plate .....	25
2.8.3 Installing the SP Ribbon Guides .....	26
2.8.4 Installing the Ribbon Tension Sheet .....	27
2.8.5 Loading the Cold Release Ribbons .....	28
<b>3. Printing .....</b>	<b>29</b>
3.1 Installing the Printer Driver .....	29
3.1.1 System Requirements .....	29
3.1.2 Installation Procedure (For Windows®98) .....	29
3.1.3 Uninstalling the Printer Driver .....	35
3.2 Properties .....	37
3.2.1 Displaying Printer Properties .....	37
3.2.2 Summary of Properties .....	38
3.3 Page Setup .....	39
3.3.1 Selecting a label size .....	39
3.3.2 Creating a new label size .....	40
3.3.3 Orientation .....	41
3.3.4 Miscellaneous .....	42
3.4 Graphics .....	46
3.4.1 Dithering .....	46
3.4.2 Intensity .....	47
3.4.3 Color .....	47
3.4.4 Color Registration .....	47
3.4.5 Spot Color Setup .....	49
3.4.6 Spot Color Printing .....	50
3.5 Bar Fonts .....	51
3.5.1 Specifying a New Font Style .....	52

3.6 Stock .....	54
3.6.1 Print Method .....	54
3.6.2 Sensor .....	54
3.6.3 Label Gap .....	54
3.6.4 Issue Settings .....	55
3.6.5 Fine Adjustment .....	56
3.7 Options .....	57
3.7.1 Transfer Mode .....	57
3.7.2 Print Density Adjustment .....	57
3.8 Device Settings .....	58
3.8.1 Maintenance .....	59
3.8.2 Testing .....	59
3.9 Print Test .....	60
3.9.1 Procedures .....	60
3.10 Printing a Label .....	61
<b>4. Online Mode .....</b>	<b>64</b>
4.1 Operation Panel .....	64
4.2 Operation .....	65
4.3 Reset .....	65
<b>5. Maintenance .....</b>	<b>66</b>
5.1 Cleaning .....	66
5.1.1 Print Head/Platen .....	66
5.1.2 Pinch Roller/Feed Roller/Media Guide .....	67
5.1.3 Fan Filters .....	67
5.1.4 Covers and Panels .....	68
5.1.5 Ribbon Modules .....	68
<b>6. Troubleshooting .....</b>	<b>69</b>
6.1 Error Messages .....	69
6.2 Possible Problems .....	71
6.3 Removing Jammed Media .....	72
6.3.1 From the Pinch Roller Unit .....	72
6.3.2 From the Print Head Block .....	72
6.4 When the Ribbon is Torn Apart .....	73
<b>Appendix 1 Specifications .....</b>	<b>74</b>
A1.1 Printer .....	74
A1.2 Options .....	75
A1.3 Media .....	75
A1.3.1 Media Type .....	75
A1.3.2 Detection Area of the Transmissive Sensor .....	76
A1.3.3 Detection Area of the Reflective Sensor .....	77
A1.3.4 Effective Print Area .....	77
A1.4 Ribbon .....	78
<b>Appendix 2 DIP Switches .....</b>	<b>79</b>
A2.1 DIP Switch A .....	80
A2.2 DIP Switch B .....	81
A2.3 Ribbon Near End Detection .....	82
<b>Appendix 3 Quick Reference for Printing .....</b>	<b>83</b>
<b>Appendix 4 Message and LED .....</b>	<b>86</b>
<b>Appendix 5 System Mode .....</b>	<b>88</b>
A5.1 Operation Panel .....	88
A5.2 Overview .....	89
A5.3 Self-Diagnostic Test .....	91
A5.4 Parameter Setting .....	92
A5.5 Test Print .....	101
A5.6 RAM Clear .....	104
A5.7 Additional Information .....	106
A5.7.1 Self-Diagnostic Test Result Sample and Descriptions .....	106
A5.7.2 Maintenance Counter/Parameter Check Print Sample and Descriptions .....	107
A5.7.3 Cut Operation Example .....	108
A5.7.4 Pulse Motor Speed .....	108
A5.7.5 X-Coordinate Fine Adjustment .....	108
A5.7.6 Magnified Views of Slant Line Pattern .....	108
A5.7.7 Initial Values after Clearing the Maintenance Counter (MAINTE.CNT.CLEAR) .....	109
A5.7.8 Initial Values after Clearing the Parameter (PARAMETER CLEAR) .....	110
A5.7.9 Initial Values after Clearing the Print Distance (PRINT STEP CLEAR) .....	111
<b>Appendix 6 Interface .....</b>	<b>112</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/TEC/CB-416-T3\\_owners\\_manual.html](https://the-checkout-tech.com/manuals/TEC/CB-416-T3_owners_manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)