


TEC Thermal Printer

TRST-56 SERIES

Owner's Manual



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

| | | | Page |
|----|------------------------|---|------|
| 1. | PRO | DDUCT OVERVIEW | 1- 1 |
| | 1.1 | Introduction | 1- 1 |
| | 1.2 | Features | |
| | 1.3 | Applicable Model | |
| | 1.4 | Accessories | 1- 2 |
| 2. | SPECIFICATIONS | | 2- 1 |
| | 2.1 | Printer | 2- 1 |
| | 2.2 | Receipt Roll | 2- 2 |
| 3. | APPEARANCE | | 3- 1 |
| | 3.1 | Front/Rear View | 3- 1 |
| | 3.2 | Operation Panel | 3- 1 |
| | 3.3 | Connectors | 3- 2 |
| 4. | SET UP PROCEDURE | | 4- 1 |
| | 4.1 | Requirements for Operation | 4- 1 |
| | 4.2 | Setting up the Printer | 4- 2 |
| 5. | INSTALLATION PROCEDURE | | 5- 1 |
| | 5.1 | Connecting the Power Cord and Interface Cable | 5- 1 |
| | 5.2 | Connecting the Drawer | |
| | 5.3 | Loading the Receipt Roll | 5- 3 |
| | 5.4 | Adjusting the Paper Near End Sensor Position | 5- 4 |
| | 5.5 | Self Test Print | 5- 5 |
| 6. | GENERAL MAINTENANCE | | 6- 1 |
| | 6.1 | Cleaning | 6- 1 |
| | | 6.1.1 Cleaning the Print Head and Platen | |
| | | 6.1.2 Cleaning the Covers | |
| | 6.2 | Removing Jammed Paper | 6- 1 |
| 7 | TDC | NIBI ESHOOTING | 7 1 |

CAUTION!

- 1. This manual may not be copied in while or in part without prior written permission of TOSHIBA
- 2. The contents of this manual may be changed without notification.
- 3. Please refer to your local Authorised Service representative with regard to any queries you may have in this manual.

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net