



# Zebra® LP 2824™ Desktop Printer

## User Guide



# Contents

## Introduction

Hello! . . . . .	1
What's in the Box? . . . . .	2
Inspecting the Printer . . . . .	3
Opening the printer . . . . .	3
Closing the printer . . . . .	5
Reporting Damage . . . . .	6
Related Documentation . . . . .	6

## Getting Started

Modes of Printing . . . . .	7
Attaching Power Supply . . . . .	8
Loading Roll Media . . . . .	9
Adjusting the Roll Holders . . . . .	9
Placing the Roll in the Media Compartment . . . . .	10
Using the Guides . . . . .	11
Operator Controls . . . . .	12
Power Switch . . . . .	12
Feed Button . . . . .	12
Status Light . . . . .	12
Media Length Sensing . . . . .	13
Hooking Up the Printer and Computer . . . . .	14
Interface Cable Requirements . . . . .	14
USB Interface Requirements . . . . .	15
Parallel Interface Requirements . . . . .	15
Ethernet Interface Requirements . . . . .	15
Serial Interface Requirements . . . . .	15
Communicating with the Printer . . . . .	16
Universal Serial Bus (USB) Communications . . . . .	16
Parallel Communications . . . . .	16
Internal Ethernet Communications . . . . .	16
Serial Communications . . . . .	17
Adjusting the Print Width . . . . .	18
Adjusting the Print Quality . . . . .	18

## **Operation & Options**

Thermal Printing . . . . .	19
Replacing Supplies . . . . .	20
Printing in Peel-Mode . . . . .	21
Printing on Fan-Fold Media . . . . .	22
Using the Cutter Option. . . . .	23

## **Maintenance**

Cleaning. . . . .	25
Print Head Considerations . . . . .	26
Media Path Considerations . . . . .	26
Cleaning Card Considerations . . . . .	26
Platen Considerations . . . . .	27
Lubrication . . . . .	27
Replacing the Platen . . . . .	28
Replacing the Print Head. . . . .	29
Direct-Thermal LP Model. . . . .	30

## **Troubleshooting**

Print Quality Problems . . . . .	36
Manual Calibration . . . . .	38
Resetting the Factory Default Values . . . . .	39
Communications Diagnostics . . . . .	39
Feed Button Modes . . . . .	40

## **Appendix**

Interfaces . . . . .	41
Universal Serial Bus (USB) Connector. . . . .	41
Parallel Interface . . . . .	42
Internal Ethernet PrintServer . . . . .	43
Serial (RS-232) Connector . . . . .	44
Serial (RJ-11) Alternative Connector . . . . .	45

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Zebra/LP-2824 user manual.html](https://the-checkout-tech.com/manuals/Zebra/LP-2824%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)