

ACUWEIGH CORPORATION

# **WEIGHING INDICATOR**

**Model:AC 03A**

## **Operation Manual**

# CONTENTS

1.0 INTRODUCTION .....	3
2.0 SPECIFICATIONS .....	4
2.1 KEYBOARD AND DISPLAY.....	4
3.0 OPERATIONS .....	6
3.1 POWER.....	6
3.2 ZEROFUNCTION.....	6
3.3 TARE FUNCTION .....	6
3.4 PRESET TARE FUNCTION.....	7
3.5 MANUAL MEMORY ACCUMULATION.....	7
3.6 AUTOMATIC MEMORY ACCUMULATION.....	7
3.7 SWITCH BETWEEN KILOGRAM TO POUND.....	8
3.8 HOLD FUNCTION.....	8
3.9 ANIMAL WEIGHING.....	8
4.0 RS-232 INTERFACE ..	9
4.1 CONNECTIONS.....	9
4.2 CONTINUOUS OUTPUT.....	9
4.3 AUTOMATIC OUTPUT.....	10
4.4 MANUAL PRINTING .....	12
5.0 BATTERY MANAGEMENT.....	13
6.0 TECHNICAL DESCRIPTION .....	13
6.1 PURPOSE.....	13
6.2 LOAD CELL CONNECTIONS .....	14
6.3 CONFIGURATION .....	14
6.3.1 METROLOGICAL PARAMETERS .....	14
6.3.2 USER PARAMETERS.....	18
7.0 ERROR CODES .....	20
8.0 TROUBLE-SHOOTING GUIDE .....	21

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Accuweigh/AC-03A Indicator operation manual.pdf](https://the-checkout-tech.com/manuals/Accuweigh/AC-03A%20Indicator%20operation%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)