

# ***ACOM***

**OWNER'S MANUAL**

**MODEL: JW-1**

**TOP LOADING BALANCE**



**VER 1.10**

# TABLE OF CONTENTS

SPECIFICATIONS .....	1
NOMENCLATURE .....	1
FUNCTION KEYS .....	2
DISPLAY .....	3
UNPACKING & ASSEMBLY .....	4
SAFETY PRECAUTIONS .....	5
OPERATING THE BALANCE .....	5
SETTINGS MODE .....	8
DENSITY MEASUREMENT OPTION .....	10
WEIGH RANGES .....	10
TROUBLESHOOTING & ERROR MESSAGES .....	11
CALIBRATION .....	12
ENABLE & DISABLE WEIGHING UNITS .....	13

## **PREFACE**

Acom Corporation would like to thank you for purchasing our model JW-1 Advanced top loading balance. We are committed to creating high quality low maintenance products and supplying our customers with diligent customer service. This manual contains information on the proper assembly and use of the scale.

### **Disclaimer:**

This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributors, or its dealers) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Brand and product names are trademarks and/or registered trademarks of their respective companies.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*