

ACOM

OWNER'S MANUAL

MODEL: LS-100

LABEL PRINTING SCALE



VER 1.70

TABLE OF CONTENTS

General	
Introduction	1
Specifications	1
Options & Accessories	2
Support & Service	2
Unpacking & Assembly	
Box Contents	3
Assembling the Display	4
Nomenclature	
Scale Overview	4
Displays	7
Printer & Label Installation	8
Numeric Keypad	11
Speed Keys	12
Alpha Keypad	13
Proper Operation	
Safety First	14
Do's & Don'ts	15
Location & Environment	16
Maintenance	16
Power Requirements	18
Set Up	
Quick Start	19
Password	21
General Programming	
Main Menu	22
Time & Date	23
Store Name & Address	24
Scale Number	24
Groups	25
Group Assignment	26
Label Settings	26
Password Change	28
PLU Programming	
Miscellaneous PLU Commodity Name	28
Creating & Editing PLUs	29
Speed Keys	37
Quick Price Change	37
Deleting PLUs	38
Advanced Programming	
Print Field Suppression	39
Temporary Date Print Inhibit	40

Barcode Settings	41
Backlight Settings	43
Date Format	43
Auto Print Setting	44
PLU Temporary Price Change Setting	44
PLU List	45
Deleting All PLUs	46
PLU Memory Status	47
Sales Mode	
PLU Key & Calling Up PLUs	47
Miscellaneous PLUs	48
Zero Key	49
Tare Key	50
Save Key	51
Auto Key	52
Pre-Pack Key	52
Set Key	53
Esc Key	53
Func. Key & Voiding	54
X Key	54
For Key	55
Feed Key	55
Print Key	57
C Key (Clear)	57
1/2 & 1/4 Keys: Fractional Pricing	58
X/Z Mode: Sales Reports	
X: Group Sales	59
X: PLU Sales	60
Z: Scale Sales	61
Advanced Topics	
Scale-to-Scale Data Transfer	63
PC-to-Scale Data Transfer	64
Self Test	64
Appendix A: Label Format Library	65
Notes: Acom Authorized Dealer	70

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*