


## LABEL/RECEIPT PRINTING SCALE

# ***NETS***

## OPERATING MANUAL TARE VER 1.0



**VER 1.00**

# TABLE OF CONTENTS

## General

Introduction .....	1
Specifications .....	1
Options & Accessories .....	2

## Unpacking & Assembly

Box Contents .....	3
Assembling the Display .....	4

## Nomenclature

Scale Overview .....	4
Displays .....	7
Printer & Label Installation .....	8
Numeric Keypad .....	11
Speed Keys .....	12
Alpha Keypad .....	12

## Proper Operation

Do's & Don'ts .....	14
Location & Environment .....	15
Maintenance .....	15
Power Requirements .....	17

## Set Up

Quick Start .....	18
Password .....	20

## Program Mode

Main Menu .....	21
P1. Creating & Editing PLUs .....	23
P2. Speed Keys .....	31
P3-1. Store Name & Address .....	32
P3-2. Groups .....	32
P3-3. Operators .....	33
P3-4. Sale Message(Receipt) .....	34
P3-5. Tax(Receipt) .....	36
P4. Time & Date .....	38
P5-2. Group Assignment .....	38
P5-3. Scale Number .....	39
P5-4. Date Format .....	39

P5-5. Backlight Setting .....	39
P5-6. Barcode Setting .....	40
P5-7. Select User(Receipt) .....	42
P5-8. Feed Length(Receipt) .....	43
P5-9. Price Rounding(Receipt) .....	43
P5-10. Operator Assignment .....	44
P5-11. Sales MSG Assignment (Receipt) .....	44
P5-12. Input Scale Counter .....	45
P5-13. Sale Function Setting .....	45
P6. Account Report .....	46
P6-1,2. X1- Report, X2-Report .....	46
P6-3. Z-Report .....	52
P7-1. Select Label or Receipt .....	54
P7-2. Set Label Length .....	55
P7-3. Set Label Gap .....	55
P7-4. Set Peel off Sensor .....	56
P7-5. Label Peel Adjustment (Label) .....	56
P7-6, 7. Gap & Peel off Threshold .....	58
P7-8. Label Format Setting .....	58
P7-9. Print Field .....	59
P7-10. Select Print Speed .....	61
P7-11. Select Print Brightness .....	61
P7-12. Select Print Counter .....	61
P7-13. Senser Setting .....	62
P8-1. Self Test .....	63
P8-2. Print PLU List .....	63
P8-3. Scale to Scale Data Transfer .....	64
P8-4. PLU Temporary Price Change Setting .....	65
P8-6. PLU Memory Status .....	66
P8-7. Deleting PLU .....	66
P8-8. Deleting All PLUs .....	67
P8-9. Password Change .....	67
PLU Quick Price Change .....	68
Temporary Date Print Inhibit .....	69
Select Format .....	69
Label / Receipt .....	69
Account .....	70

## **Sales Mode**

Change Initial State Display .....	70
PLU Key & Calling Up PLUs .....	71
Zero Key .....	73
Tare Key .....	73
Save Key(Label) .....	74
Auto Key(Label) .....	75
Set Key .....	76
Label/Receipt Key .....	76
REFUND/Esc Key.....	76
ADD Key .....	77
X/Sub Total Key .....	78
For Key .....	78
Clear Key .....	79
Feed Key .....	80
Print Key .....	81
Void Function .....	82
Discount Function (Receipt) .....	82
Change & Tender Print (Receipt) .....	83
Multi User Operation (Receipt) .....	83

## **Advanced Topics**

PC-to-Scale Data Transfer .....	85
---------------------------------	----

<b>Appendix A: Label Format Library</b> .....	86
---	----

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*