

Operating manual

MODEL : PC-100

POS ECR Interface

ACOM

Gratitude

Thank you for your purchasing our product, we are always trying to serve you with a good quality as a reliable weighing instrument and enhanced features to supporting various kinds of conveniences of conveniences

Specifications

Items	PC-100 (ECR Interface)		
	6 kg	15 kg	30 kg
Minimum graduation	2 g	5 g	10 g
Maximum Tare	Full tare		
A/D update speed	9 times / sec.		
Internal resolution	60,000		
Display(digit)	VFD Weight(5)		
Operating temp.	-10°C ~ 40°C		
Humidity	RH.35% ~ 85%(no condensation)		
Power source	AC 115, 230 / 50, 60Hz		
Power consumption	AC only Approx. 6W		
Fuse rating	250V / 0.2A		
Platter size/mm(inch)	350(13.8) x 270(10.6)		
Size mm(inch)	Poled -> 365(14.4) x 365(14.4) x 470(18.5)		

Precautions

- Place the scale on the flat and rigid surface
- Place the scale far away from heavy EMI noises
- Level the scale with adjusters
- Do not subject the impact on the scale
- Do not use cleaner included solvent or sinner
- The scale must be calibrated by authorized person initially and regularly under an each country's related law

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/acom/PC-100 ECR Cable Diagrams manual.htm>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)