




Adam Equipment

AZ_{extra} SERIES

(P.N. 3026610533, Revision A2, August 2009)



Adam Equipment strives to be more environmentally focused and uses recycled materials and environmentally friendly packaging where possible. As part of this initiative we have developed a short form manual that uses less paper and ink to describe the main functions of your new Adam scale. A complete version is available at www.adamequipment.com. Thank you for your support of Adam Equipment and we hope that you enjoy your new scale.

CONTENTS

1.0	OPERATION	2
1.1	SETTING UP AND TURNING ON THE SCALES	2
1.2	ZEROING AND TARING	2
1.3	DETERMINING VALUE OF A PRODUCT BY WEIGHT	3
1.4	USING A STORED PLU VALUE FOR UNIT PRICE	3
1.5	STORING VALUES FOR THE PLU s	3
2.0	RS-232 INTERFACE	4
2.1	<i>INPUT COMMANDS FORMAT</i>	4
3.0	PARAMETER	5
3.1	<i>AUTO SLEEP FUNCTION</i>	5
3.2	<i>BACKLIGHT OPERATION</i>	5
3.3	<i>RS-232 SETUP</i>	5
3.4	<i>REAL TIME CLOCK SETUP</i>	6
4.0	ERROR CODES	6
5.0	CALIBRATION	6
6.0	SPECIFICATIONS	7
7.0	SERVICE INFORMATION	8

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/adam equipment/AZ extra operating manual.htm](https://the-checkout-tech.com/manuals/adam%20equipment/AZ%20extra%20operating%20manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)