



## **CBK SERIES**

(P.N. 8509, Revision A7, August 2007)

Software Rev.: 4.28 & above  
4.25H & above for CBK 8H/16aH

# CONTENTS

1.0	INTRODUCTION.....	2
2.0	SPECIFICATIONS.....	3
3.0	INSTALLATION.....	4
3.1	UNPACKING.....	4
3.2	LOCATING .....	5
3.2	SETTING UP .....	6
4.0	KEYPAD.....	7
5.0	DISPLAY .....	8
6.0	SYMBOLS AND INDICATORS .....	8
7.0	BATTERY.....	9
8.0	BACKLIGHT .....	9
9.0	AUTO POWER OFF.....	9
10.0	OPERATIONS.....	10
10.1	ZEROING.....	10
10.2	TARING .....	10
10.2.1	Manual tare.....	10
10.2.2	Preset Tare .....	11
10.3	WEIGHING .....	11
10.4	PARTS COUNTING.....	11
10.5	CHECK-WEIGHING .....	13
10.5.1	Setting up check-weighing while weighing.....	14
10.5.2	Setting up check-weighing while parts counting or % weighing.....	14
10.6	LIMITS STORING AND RECALLING.....	15
10.7	PERCENT WEIGHING .....	16
10.8	ACCUMULATED TOTAL.....	17
10.8.1	Manual Accumulation .....	18
10.8.2	Automatic Accumulation .....	19
11.0	RS-232 INTERFACE .....	20
11.1	INPUT COMMANDS FORMAT.....	22
12.0	CALIBRATION .....	23
13.0	PARAMETER SETTINGS .....	24
13.1	CHECK WEIGHING PARAMETERS.....	24
13.2	RS-232 PARAMETERS.....	26
13.3	SCALE PARAMETERS .....	27
14.0	ERROR MESSAGES .....	29
15.0	REPLACEMENT PARTS AND ACCESSORIES .....	30
16.0	SERVICE INFORMATION.....	30
17.0	WARRANTY INFORMATION.....	31
18.0	APPENDIX .....	32

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*