




Adam Equipment

DUNE SERIES

(P.N. 9384, Revision A, April 2008)



1.0 CONTENTS

1.0	CONTENTS.....	3
2.0	INTRODUCTION.....	3
3.0	SET UP.....	4
3.1	UNPACKING AND SETTING UP YOUR SCALE.....	4
3.2	LOCATING AND PROTECTING YOUR SCALE.....	5
4.0	BASIC OPERATION.....	6
4.1	TURING ON THE SCALE.....	6
4.2	ZEROING / TARE.....	6
4.4	WEIGHING.....	6
5.0	FUNCTIONS.....	7
5.1	AUTO POWER OFF.....	7
6.0	CALIBRATION.....	7
7.0	TROUBLE SHOOTING.....	8
7.1	ERROR MESSAGES.....	8
7.2	REPLACEMENT PARTS AND ACCESSORIES.....	8
8.0	SPECIFICATIONS.....	9
9.0	WARRANTY STATEMENT.....	10

2.0 INTRODUCTION

Thank you for purchasing the **Dune™** compact scales, Every **Dune** is equipped with the features you really need: AC adapter, auto-calibration through the keypad, low-battery indicator, and overload indicator. With its alternate battery operation, splash-proof key pad, and sturdy plastic construction throughout, the Dune will deliver accurate readings both indoors and out.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/adam equipment/Dune Series user manual.html](https://the-checkout-tech.com/manuals/adam%20equipment/Dune%20Series%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)