




Adam Equipment

HIGHLAND SERIES

(P.N. 9520, Revision D1, September 2008)



1.0 CONTENTS

1.0	Contents.....	3
2.0	Introduction	4
3.0	Set Up	4
3.1	Unpacking And Setting Up Your Balance	4
3.2	Display / Keyboard Function	5
3.3	Internal Rechargeable Battery	6
3.4	Locating And Protecting Your Balance	7
3.5	Storing When Not In Use	8
4.0	Basic Operation	9
4.1	Turning On The Balance	9
4.2	Zeroing / Tare	9
4.4	Weighing.....	10
4.5	Weighing Units.....	10
5.0	Functions.....	11
5.1	Percentage Weighing.....	11
5.2	Parts Counting	11
5.3	Accumulation	12
6.0	Parameters	14
6.1	Enabling Weighing Units	14
6.2	Setting The Backlight	15
6.3	Setting The Printing Parameters / Accumulation.....	16
6.4	Auto Power Off	18
6.5	Selecting The Internal Or External Calibration.....	18
6.6	Adjust The Value Of The Internal Mass.....	19
7.0	Calibration	20
8.0	Trouble Shooting.....	22
8.1	Error Messages	22
8.2	Replacement Parts And Accessories.....	23
9.0	Specifications	24
9.1	Technical Specifications.....	24
9.2	Common Specifications	24
9.3	RS-232 and USB Specifications	24
10.0	Calibration Certificate	26
11.0	Warranty Statement	26

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/adam equipment/HCB Highland Series user man](https://the-checkout-tech.com/manuals/adam%20equipment/HCB%20Highland%20Series%20user%20man)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)