



PW SERIES

(P.N. 8081, Revision E4, September 2007)

Software rev.: 2.43 & above

TABLE OF CONTENTS

1.0 KNOW YOUR BALANCE	5
2.0 SPECIFICATIONS	6
3.0 UNPACKING THE BALANCE	7
4.0 LOCATING THE BALANCE	7
5.0 SETTING UP THE BALANCE	8
5.1 ASSEMBLING THE BALANCE	8
5.2 LEVELLING THE BALANCE	8
5.3 WARM-UP TIME	8
6.0 DISPLAY	9
7.0 KEYPAD	11
7.1 NUMERIC ENTRY METHOD	11
8.0 INPUT/OUTPUT	12
9.0 OPERATIONS	13
9.1 INITIALISATION	13
9.2 PASSCODES	13
9.3 WEIGHING	14
9.3.1 Weighing Units	14
9.4 FUNCTIONS	15
9.4.1 Parts Counting	16
9.4.2 Percent Weighing	17
9.4.3 Check Weighing	18
9.4.4 Animal / Dynamic Weighing	19
9.4.5 Net/Total	22
9.4.6 Density Determination	23
10.0 CALIBRATION	25
10.1 MANUAL CALIBRATION	25
10.1.1 Calibration using Internal Calibration mass	25
10.1.2 Calibration using External Calibration mass	25
10.2 AUTOMATIC CALIBRATION	26
10.3 CALIBRATION ERRORS	26
11.0 RS-232 INTERFACE	27
12.0 ERROR CHECKING	30
13.0 SUPERVISOR MENUS	30
13.1 ENABLE WEIGHING UNITS	31

- 13.2 ENABLE WEIGHING MODES 31
- 13.3 ENABLE SERIAL INTERFACE PARAMETERS 31
- 13.4 SETUP PARAMETERS 33
- 13.5 CALIBRATION SETUP 34
 - 13.5.1 INTERNAL CALIBRATION MASS ADJUSTMENT 35
- 13.6 PASSCODES..... 36
 - 13.6.1 Forgotten Passcodes 37
- 14.0 PERIPHERALS** 37
 - 14.1 DENSITY DETERMINATION KIT 37
 - 14.2 ANTI-VIBRATION TABLE 37
 - 14.3 ADAM PRINTERS 37
- 15.0 SAFETY AND MAINTENANCE** 38
- 16.0 TROUBLE-SHOOTING** 38
- 17.0 REPLACEMENT PARTS AND ACCESSORIES** 42
- 18.0 SERVICE INFORMATION** 42

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/adam equipment/PW Series user manual.html](https://the-checkout-tech.com/manuals/adam%20equipment/PW%20Series%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)