



WBW SERIES
WBW..M EC Type Approved
(P.N. 9031, Revision D1, July 2009)

Software Rev 2.00 (WBW and WBWa)
Rev. 2.02 (WBW-M)

CONTENTS

1.0	INTRODUCTION.....	3
2.0	SPECIFICATIONS.....	4
3.0	INSTALLATION.....	6
3.1	UNPACKING.....	6
3.2	LOCATING.....	6
3.3	SETTING UP.....	7
4.0	KEYPAD.....	8
4.1	NUMERIC ENTRY METHOD.....	8
5.0	DISPLAY.....	9
6.0	SYMBOLS AND INDICATORS.....	9
7.0	BATTERY OPERATION.....	10
8.0	BACKLIGHT.....	10
9.0	AUTO POWER OFF.....	10
10.0	OPERATIONS.....	11
10.1	ZEROING.....	11
10.2	TARING.....	11
10.3	WEIGHING.....	12
10.4	CHECK-WEIGHING.....	12
10.5	LIMITS STORED IN MEMORY.....	13
11.0	RS-232 INTERFACE.....	13
12.0	CALIBRATION.....	14
12.1	WBW-M APPROVED SCALES, CALIBRATION PROCEDURE.....	14
12.2	SECURITY SEALS.....	14
12.3	CALIBRATION COUNTER.....	15
12.4	WBW SERIES , NOT APPROVED.....	15
13.0	PARAMETER SETTING.....	17
13.1	CHECK WEIGHING PARAMETERS.....	17
13.2	SCALE PARAMETERS.....	18
14.0	ERROR CODES.....	19
15.0	REPLACEMENT PARTS AND ACCESSORIES.....	20
16.0	SERVICE INFORMATION.....	20
17.0	WARRANTY INFORMATION.....	21

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*