


AD-4323

Weighing Indicator



MAINTENANCE MANUAL

maintenance-AD-4323-v.1.c 89.09.30 OYM



CONTENTS

Warranty, FCC Rules	Page 2
Specifications	Page 3
General	Page 7
Method	Page 7
A/D Converter	Page 8
Block Diagram	Page 9
Software Flow Chart	Page 10
Main Routine Flow Chart	Page 11
Calibration Flow Chart	Page 12
Front Panel Description	Page 13
Rear Panel Description	Page 16
Self-Check Mode	Page 17
Check Mode	Page 18
Entering the Check Mode	Page 18
Setpoint Input Pins A-5~A-8	Page 18
Setpoint Input Pins A-9~A-12.....	Page 18
Setpoint Input Pins B-1~B-4	Page 19
Setpoint Input Pins B-5~B-8	Page 19
Control I/O Interface Check	Page 19
Front Panel Key Switch Check	Page 19
Options Check	Page 20
Non-Volatile Memory Check	Page 20
Power Board Check	Page 21
Initialization	Page 22
Setting to Meet Individual Regulation.....	Page 23
Circuitry	Page 25
A/D Control Circuit	Page 26
Waveform Check	Page 27
Watchdog Circuit	Page 27
I/O Circuit	Page 28
Setpoint Circuit	Page 28
IC6 Circuit	Page 29
Keyboard Circuit Diagram	Page 30
Display Board Diagram	Page 31
Main Board Circuit Diagram	Page 32
Dimensions.....	Page 33
Diagrams.....	Appendices

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/AnD/AD-4323 service manual.html](https://the-checkout-tech.com/manuals/AnD/AD-4323%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)