EK-i/EW-i Series Compact Balances

EK-120; / EK-200; / EK-300; / EK-600; EK-1200; / EK-2000; / EK-3000; / EK-6000; / EK-12K; EW-150; / EW-1500; / EW-12K;

Maintenance Manual



1.	Introduction3)
2.	Block diagram5	,
3.	Trouble shooting6	5
4.	Calibration mode	7
4.1	Calibration using a weight	7
4.2	2 Gravity acceleration correction)
4.3	Calibration of the CAL prohibition models10)
4.4	Cancelation of CAL prohibition mode1)
4.5		
4.6	Set the CAL prohibition mode 10)
5.	Disassembling and Assembling11	l
5.		
5.2		
6	Internal settings17	7
6.		
	.1.1 Input the characteristic revised data of load cell	
	.1.2 Calibration procedure for maintenance load cell	
	Setting for replacing the main board / E2PROM	
	.2.1 Initialize	
	.2.2 Setting of function 18	
6	.2.3 Input the adjustment data 18	8
6	.2.4 Calibration	9
7.	Check mode20)
7.	•	
7.2	2 Adjustment group 2	1
7	.2.1 tESt (display/key/port check)	1
7	.2.2 d-dSP (The internal data) 2	1
8.	Function setting mode23	3
8.		
8.		
8.		
۵,	4 d-SEt (Internal data setting)	

8.5 C–Function list	27
9. Specification	30 31
10. Dimensions	33
11. Maintenance	34
12. Circuit diagram of PZ3762	37
13. Parts layout of PZ:3762	39
14. Parts list of circuit (PZ:3762)	41
15.1 OP-04 Comparator relay output and buzzer	43
16. Circuit diagram of PZ:3764	45
17. Parts layout of PZ:3764	46
18. Parts list of circuit (PZ:3764)	47
19. Circuit diagram of PZ:3765	48
20. Parts layout of PZ3765	49
21. Parts list of circuit (PZ:3765)	51
22. Exploded view and parts list	53

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net