

FG Series

Digital Platform Scales

FG-60KAL / FG-150KAL

FG-30KAM / FG-60KAM / FG-150KAM

FG-30KBM / FG-60KBM / FG-150KBM

INSTRUCTION MANUAL



Contents

1. INTRODUCTION	2
2. UNPACKING	2
3. NAMES AND FUNCTIONS	3
4. SETTING UP	6
4-1. Attaching a display pod to the base (FG-KAL and FG-KAM)	6
4-2. Installing the scale	6
4-3. Power source.....	7
5. BASIC OPERATION	8
5-1. Turning the power ON and OFF	8
5-2. Selecting a weighing unit.....	8
5-3. Basic operation.....	8
5-4. Weight display resolution.....	9
6. COUNTING MODE	10
7. COMPARATOR	11
8. CALIBRATION	12
8-1. Calibration using a weight.....	12
8-2. Gravity acceleration correction	13
9. FUNCTIONS	14
9-1. The procedure for setting parameters.....	14
9-2. Function list	15
10. OPTIONS	16
10-1. Installation of OP-23/OP-24.....	16
10-2. OP-23 RS-232C serial interface	17
10-3. OP-24 RS-232C serial interface and Comparator relay output.....	20
11. MAINTENANCE	21
11-1. Notes on maintenance	21
11-2 Error codes	21
12. SPECIFICATIONS	22
12-1. Specifications.....	22
12-2. Dimensions.....	23
GRAVITY ACCELERATION MAP	24

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/AnD/FG-30 FG-60 FG-150 KAL KAM KBM instru>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)