

FZ-*i* / FX-*i* SERIES

FZ-120*i* / FZ-200*i* / FZ-300*i*
FZ-1200*i* / FZ-2000*i* / FZ-3000*i*

FX-120*i* / FX-200*i* / FX-300*i*
FX-1200*i* / FX-2000*i* / FX-3000*i*

Precision Balance

INSTRUCTION MANUAL



CONTENTS

Basic Operation

1. INTRODUCTION	3
1-1 About This Manual.....	3
1-2 Features	3
1-3 Compliance.....	4
2. UNPACKING THE BALANCE	5
2-1 Unpacking.....	5
2-2 Installing the Balance	6
3. PRECAUTIONS	7
3-1 Before Use.....	7
3-2 During Use.....	7
3-3 After Use	8
3-4 Power Supply	8
3-5 Display Symbols and Key Operation.....	9
4. WEIGHING UNITS	10
4-1 Units.....	10
4-2 Storing Units	12
5. WEIGHING	13
5-1 Basic Operation (Gram Mode)	13
5-2 Counting Mode (PCS)	14
5-3 Percent Mode (%).....	16
5-4 Statistical Calculation Mode	17
5-5 Statistical Calculation Mode (Example of Use)	21

Adapting to the Environment

6. RESPONSE ADJUSTMENT	23
7. CALIBRATION	24
7-1 Calibration Mode	24
7-2 Calibration Using the Internal mass (One-Touch Calibration, only for FZ- <i>i</i> series).....	25
7-3 Correcting the Internal Mass Value (Only for FZ- <i>i</i> series)	26
7-4 Calibration Using an External Weight.....	27
7-5 Calibration Test Using an External Weight.....	29
8. FUNCTION SWITCH AND INITIALIZATION.....	31
8-1 Permit or Inhibit	31
8-2 Initializing the Balance.....	32

Functions

9. FUNCTION TABLE	33
9-1 Structure and Sequence of the Function Table	33

9-2 Display and Keys	33
9-3 Details of the Function Table	34
9-4 Description of the Class "Environment, Display"	37
9-5 Description of the Item "Data Output Mode"	39
9-6 Description of the Item "Data Format"	40
9-7 Data Format Examples	42
9-8 Description of the Item "Application Function"	43
9-9 Clock and Calendar Function	44
9-10 Comparator Function	46
10. ID NUMBER AND GLP REPORT	47
10-1 Setting the ID Number	47
10-2 GLP Report	47
11. UNDERHOOK	51
12. PROGRAMMABLE-UNIT	52
RS-232C Serial Interface	
13. RS-232C SERIAL INTERFACE	53
14. CONNECTION TO PERIPHERAL EQUIPMENT	54
14-1 Connection to the AD-8121B Printer	54
14-2 Connection to a Computer	55
14-3 Using Windows Communication Tools (WinCT)	55
15. COMMANDS	57
15-1 Command List	57
15-2 Acknowledge Code and Error Codes	58
15-3 Settings Related to RS-232C	59
Maintenance	
16. MAINTENANCE	60
17. TROUBLESHOOTING	61
17-1 Checking the Balance Performance and Environment	61
17-2 Error Codes	62
17-3 Asking For Repair	63
18. OPTIONS	64
19. SPECIFICATIONS	66
20. EXTERNAL DIMENSIONS	68
21. TERMS/INDEX	69

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*