
HL-*i* series Digital Compact Scale Operating Instructions

Cautions

- ❑ Avoid installing the scale in direct sunlight.
- ❑ Avoid over / shock load that could cause damage to the scale.
- ❑ Use the scale under conditions of -10°C to 40°C, less than 85% R.H.
- ❑ The weighing pan cannot be removed. Do not pull on up it.
- ❑ Do not mix the battery types. Replace all of the batteries at same time.
- ❑ If the scale is not to be used for a long period of time, remove the all batteries.
- ❑ Use only the specified AC adapter for the scale (AC adapter is optional).

Specifications

HL-200 <i>i</i>	200 x 0.1 g / 7.05 x 0.01 oz / 1000.0 x 0.5 ct / 5.335 x 0.005 tl
HL-2000 <i>i</i>	2000 x 1 g / 70.5 x 0.1 oz / 4 lb 6.6 oz x 0.1 oz / 53.35 x 0.05 tl
Power	4 x “AA” size batteries (monitor batteries included) or AC adapter
Battery life	Approximately 1000 hours with alkaline cells at 20°C / 68°F
Pan size	ϕ 130 mm / ϕ 5.1 in.
Dimensions	130 (W) x 192 (D) x 51 (H) mm / 5.1 (W) x 7.6 (D) x 2.0 (H) in

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/AnD/HL-200i and HL-2000i instruction manual.htm](https://the-checkout-tech.com/manuals/AnD/HL-200i%20and%20HL-2000i%20instruction%20manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)