

# SW Series

## *Super Wash Down Scales*

SW-6KS / SW-15KS

SW-15KM / SW-30KM / SW-60KM / SW-150KM

SW-60KL / SW-150KL

# INSTRUCTION MANUAL



---

# CONTENTS

---

<b>1. COMPLIANCE</b> .....	3
<b>2. INTRODUCTION</b> .....	4
<b>3. FEATURES</b> .....	4
<b>4. PRECAUTIONS</b> .....	5
4.1. Installing the scale .....	5
4.2. Operating the scale .....	5
4.3. Cleaning the scale .....	5
<b>5. UNPACKING</b> .....	6
<b>6. DESCRIPTION OF EACH PART</b> .....	7
6.1. Display and symbols .....	8
6.2. Switches .....	9
<b>7. SETTING UP</b> .....	10
7.1. Attaching the display pole to the base .....	10
7.2. Installing the scale .....	11
<b>8. BASIC OPERATION</b> .....	12
8.1. Turning the power ON and OFF .....	12
8.2. Selecting a weighing unit.....	13
8.3. Basic weighing operation.....	13
8.4. Weight display resolution.....	14
<b>9. COUNTING MODE</b> .....	15
<b>10. COMPARATOR</b> .....	16
10.1. The formula to compare .....	16
10.2. Entering the comparator values.....	18
<b>11. CALIBRATION</b> .....	19
11.1. Gravity acceleration correction .....	19
11.2. Calibration using a weight.....	20
11.3. Restoring the factory set values.....	21
<b>12. FUNCTIONS</b> .....	22
12.1. Setting the parameters .....	22
12.2. To restore the function settings to the factory setting values .....	22
12.3. Function list .....	23

<b>13. OPTIONS</b> .....	25
13.1. Using the OP-02 SLA battery .....	25
13.1.1. Installing the battery.....	25
13.1.2. Charging the battery .....	26
13.2. OP-03 RS-232C / RELAY OUTPUT .....	27
13.2.1. Installing OP-03 .....	27
13.2.2. OP-03 Specifications .....	28
13.2.3. Command mode.....	31
13.3. OP-04 RS-422 / 485 .....	34
13.3.1. Installing OP-04 .....	34
13.3.2. OP-04 Specifications .....	35
<b>14. MAINTENANCE</b> .....	38
14.1. Notes on maintenance.....	38
14.2. Error codes .....	38
<b>15. SPECIFICATIONS</b> .....	39
15.1. Specifications .....	39
15.2. External dimensions .....	41
<b>GRAVITY ACCELERATION MAP</b> .....	43

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/AnD/SW-6KS to SW-150KL Series instruction ma](https://the-checkout-tech.com/manuals/AnD/SW-6KS%20to%20SW-150KL%20Series%20instruction%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)